

WASHING MACHINE

OWNER'S MANUAL

PHILCO



Famous for Quality the World Over

PLD 1483 Crown
PLD 1273 Crown
PLDS 1483 Crown
PLDS 1263 Crown
PLDS 1063 Crown
PLD 16106 Crown

Before using your washing machine, please read this manual carefully and keep it for future reference.

Read This Manual

Inside you will find many helpful hints on how to use and maintain your washing machine properly. Just a little preventative care on your part can save you a great deal of time and money over the life of your washing machine. You'll find many answers to common problems in the chart of troubleshooting tips. If you review the chart of Troubleshooting Tips first, you may not need to call for service.

Dear customer,

Thank you for buying a PHILCO brand product. So that your appliance serves you well, please read all the instructions in this user's manual.

CONTENTS

PART 1: SAFETY PRECAUTIONS 2

PART 2: OVERVIEW OF WASHING MACHINE 4

PART 3: INSTALL WASHING MACHINE..... 6

PART 4: OPERATE WASHING MACHINE 10

- Checklist and Preparation before Washing Clothes 10
- View of Control Panel 14
- Select the procedure 15
- Table of Washing Procedures 18

MAINTENANCE 19

- Cleaning and Maintenance of Washing Machine Cabinet..... 19
- Troubleshooting..... 22
- Remove the problems..... 23

PART 6: APPENDIX 24

- Care Lable 24
- Product Specifications 25


PART 7: Product Fiches 26

PART 1: SAFETY PRECAUTIONS

Safety Precautions


- Sharp and rigid items such as coin, brooch, nail, screw or stone etc. may cause serious damages to this machine.
- Pull out its plug and cut off water supply after the operation.
- Please check whether the water inside the drum has been drained before opening its door. Please do not open the door if there is any water visible.
- Pets and kids may climb into the machine. Check the machine before every operation.
- Glass door may be very hot during the operation. Keep kids and pets far away from the machine during the operation.
- Take care that power voltage and frequency shall be identical to those of washing machine.
- Do not use any socket with rated current less than that of washing machine. Never pull out power plug with wet hand.
- To ensure your safety, power cord plug must be inserted into an earthed three-pole socket. Check carefully and make sure that your socket is properly and reliably earthed.
- This appliance may be used by children 8 years of age and older and by persons with physical or mental impairments or by inexperienced persons, if they are properly supervised or have been informed about how to use of the product in a safe manner and understand the potential dangers. Children must not play with the appliance. Cleaning and maintenance performed by the user must not be performed by unsupervised children.
- Children of less than 3 years should be kept away unless continuously supervised.
- Kids should be supervised to ensure that they do not play with the machine.

- Packing materials may be dangerous to the kids.
- Please keep all packing materials (plastic bags, foams etc) far away from the kids.
- Washing machine shall not be installed in bath room or very wet rooms as well as in the rooms with explosive or caustic gases.
- Make sure that the water and electrical devices must be connected by a qualified technician in accordance with the manufacturer's instructions and local safety regulations.
- Before operating this machine, all packages and transport bolts must be removed. Otherwise, the washing machine may be seriously damaged while washing the clothes.
- Before washing the clothes at first time, the washing machine shall be operated in one round of the whole procedures without the clothes inside.
- The washing machine with single inlet valve only can be connected to the cold water supply. The washing machine with double inlet valves can be connected to the hot water and cold water supply.
- Your washing machine is only for home use and is only designed for the textiles suitable for machine washing.
- Flammable and explosive or toxic solvents are forbidden.
- Gasoline and alcohol etc. Shall not be used as detergents.
- Please only select the detergents suitable for machine washing, especially for drum.
- It is forbidden to wash carpets.
- Be careful of burning when washing machine drains hot washing water.
- Never refill the water by hand during washing.
- After the program is completed, Please wait for two minutes to open the door.
- Please remember to disconnect water and power supply immediately after the clothes are washed.

- Do not climb up and sit on top cover of the machine.
- Do not lean against machine door.
- Please do not close the door with excessive forces. If it is found difficult to close the door, please check if the excessive clothes are put in or distributed well.
- The household washing machine isn't intended to be built-in.
- Cautions during Handling Machine
 1. Transport bolts shall be reinstalled to the machine by a specialized person.
 2. The accumulated water shall be drained out of the machine.
 3. Handle the machine carefully. Never hold each protruded part on the machine while lifting. Machine door can not be used as the handle during the conveyance.
- Notes on disposal:
 -  This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the collection systems or contact the retailer where the product was purchased. They return and can take this product for environmental safe recycling.

PART 2: OVERVIEW OF WASHING MACHINE

Component




- 1. Detergent Drawer
- 2. Door
- 3. Service Panel
- 4. Control Pane
- 5. Power Plug
- 6. Outlet Hose
- 7. Detergent Box


Accessories




Transport
hole plug



Inlet pipe
C



Inlet pipe
H (optional)



Outlet hose
support (optional)

PART 3: Install Washing Machine

Unpacking the washing machine

Unpack your washing machine and check if there is any damage during the transportation.

Also make sure that all the items (as shown in Page 5) in the attached bag are received.

If there is any damage to the washing machine during the transportation, or any item is missing, please contact the local dealer immediately.


Dispose the packing materials

The packing materials of this machine may be dangerous to kids. Please dispose them properly and avoid easy touch by kids. Please dispose the related packing materials according to the relevant local regulations. Please do not throw the packing materials away together with the other daily living rubbishes.

Remove transport bolts

Before using this washing machine, transport bolts must be removed from the backside of this machine. Please take the following steps to remove the bolts:

1. Loosen all bolts with spanner and then remove them.
2. Stop the holes with transport hole plugs.
3. Keep the transport bolts properly for future use.



Select the location

Before installing the washing machine, the location characterized as follows shall be selected:


- Rigid, dry, and level surface (if not level, please make it level with reference to the following figure "Adjust Leg")
- Avoid direct sunlight
- Sufficient ventilation
- Room temperature is above 0 °C
- Keep far away from the heat resources such as coal or gas.

Make sure that the washing machine will not stand on power cord.

Do not install the washing machine on the carpet floor.

Adjust Leg

1. When positioning the washing machine, please first check if the legs are closely attached to the cabinet. If not, please turn them to their original positions with hand or spanner and tighten the nuts with spanner.
2. After positioning the washing machine, press four corners on top cover of washing machine in sequence. If the washing machine is not stable when being pressed, this leg shall be adjusted.
3. Ensure the positioning status of washing machine. Loosen the lock nut with spanner and turn the leg with hand until it closely contacts with the floor. Press the leg with one hand and fasten the nut closely to the cabinet with the other hand.
4. After being locked properly, press four corners again to make sure that they has been adjusted properly. If it is still unstable, it has to repeat Steps 2 and 3.




- Put a solid cylinder (e.g. pop cans) oppositely on the top cover of the washing machine from in the left, right, front and back directions. If the cylinder keeps stable, the washing machine is positioned level. If it rolls, the washing machine is positioned unlevel. The rolling direction is the direction of lower ground surface. Then, the two legs in this direction shall be raised at the same time until the washing machine is level. Steps 1~3 are repeated to make the bottom legs closely against the ground and the nuts shall be locked tightly.

Connect inlet pipe


Connect the inlet pipe as indicated in the figure.

For the model which has hot valve, please connect the hot valve to hot water tap. Energy will decrease automatically for some program.



Install inlet pipe

- Connect the elbow to tap and fasten it clockwise.
- Connect the other end of inlet pipe to the inlet valve at the backside of washing machine and fasten the pipe tightly clockwise.




NOTE:

After connection, if there is any leakage with hose, then repeat the steps to connect inlet pipe. The most common type of tap shall be used to supply water. If tap is square or too big, then standard tap shall be changed.



Place outlet hose

There are two ways to place the end of outlet hose:

- it beside the water trough.



2. Connect it to the branch drain pipe of the trough.




- It can drain the water up and down, outlet hose shall not be installed at a height beyond 100cm and its end shall not be immersed in water.


Position outlet hose properly so that the floor will not be damaged by water leakage.

NOTE:

If the machine has outlet hose support, please install it like the following pictures.



- When installing outlet hose, fix it properly with a rope.
- Position outlet hose properly so that the floor will not be damaged by water leakage.



- If outlet hose is too long, do not force it into washing machine as it will cause abnormal noises.

Electrical Connection

- As the maximum current through the unit is 10A when you are using its heating function, please make sure the power supply system (current, power voltage and wire) at your home can meet the normal loading requirements of the electrical appliances.
- Please connect the power to a socket which is correctly installed and properly earthed.
- Make sure the power voltage at your place is same to that in the machine's rating label.
- Power plug must match the socket and cabinet must be properly and effectively earthed.
- Do not use multi-purpose plug or socket as extension cord.
- Do not connect and pull out plug with wet hand.

- When connecting and pulling out the plug, hold the plug tightly and then pull it out. Do not pull power cord forcibly.
- If power cord is damaged or has any sign of being broken, special power cord must be selected or purchased from its manufacturer or service center for replacement.

WARNING:

1. ***This machine must be earthed properly. If there is any short circuit, earthing can reduce the danger of electrical shock. This machine is equipped with power cord, which includes plug, earthing wire at earthing terminal.***
2. ***Washing machine shall be operated in a circuit separate from other electrical appliances. Otherwise, power protector may be tripped or fuse may be burned out.***

PART 4: OPERATE WASHING MACHINE

Checklist and Preparation before Washing Clothes

Please read this operation method carefully to avoid the troubles of washing machine and damages of clothes.


Check if the first-washed clothes will be decolorized.

After a white towel touched with liquid detergent is used to wash the invisible corners of the clothes, check if the white towel is stained with clothes' original color.

As for the scarves and those clothes that easily get decolorized among imported clothes, please wash them separately before washing.

As for the stains on sleeves, collars and pockets, use the liquid detergent and wash it with brush gently. Finally put them into the washing machine to achieve more ideal washing effects.

As for temperature-sensitive clothes, they shall be washed as required in the labels. Otherwise, it may cause color change or distortion.



Keep in Mind:

Never put the clothes to be washed in washing machine for a long period of time.

Otherwise it may get moldy and cause spots. Therefore, please wash the clothes in time.

The clothes also may get color changed or distorted if they are not washed according to the stated washing temperature.

Clothes that can not be washed by washing machine

The clothes that may get distorted if being immersed in water:

Ties, waistcoats, western-style clothes, outer garments etc. may have obvious shrinkage if being immersed in water; the decolorized clothes such as blended spinning clothes of artificial fiber etc.

Wrinkle-style clothes, embossed clothes, resin clothes etc. may get distorted when being immersed in water. Among cotton and wool materials, the clothes that get easily distorted are wrinkle-style silk, fur products and fur decorations;

Clothes with decoration, long dress and traditional clothes etc are the products to get decolorized easily.

Please do not wash the clothes without material labels and washing requirements.

Never wash the clothes stained with the chemicals such as gasoline, petroleum, benzene, paint thinner and alcohol.

Please pay attention with regard to detergents

"Low bubble" detergent or washing powder or washing powder special for drum washing machine shall be selected according to fiber types (cotton, synthetic fiber, soft products and wool products), colors, washing temperatures, dirty degrees and types. Otherwise, excessive bubbles may be generated and overflowed out of the drawer so that accidents may take place.

Bleacher belongs to alkali type and can damage clothes, so it is suggested to use as little as possible.

Powder detergents can easily leave the residues in the clothes so as to generate the bad smell, so they shall be sufficiently rinsed.

Detergent can not easily get dissolved completely if there is too much detergent or water temperature is rather low. It can remain in clothes, pipes and washing machines to pollute the clothes.


Washing shall follow the weight of clothes, dirty degrees, local water hardness as well as the recommendations from the detergent manufacturers. Please consult the water company if you are not clear of water hardness.

NOTE:

Keep detergents and additives in safe and dry places out of touch by kids.

Please take out the items out of the pockets.

Please check the pockets of the clothes to be washed, empty the rigid items such as decorations and coins, otherwise washing machine may be damaged or have abnormal troubles.

**For the clothes to be washed, they are classified according to the following characteristics:**

The symbol types of care labels: the clothes to be washed are classified into cotton, blended fiber, synthetic fiber, silk, wool and artificial fiber.

Color: white and colorful colors shall be identified. All new colorful articles shall be washed in a separate way.

Size: the articles of different sizes are washed together to increase the washing effects.

Sensitivity: soft articles shall be washed separately. As for new pure wool textiles, curtains and silks, the soft washing procedure shall be selected. Check the labels in all washing articles.

The clothes shall be sorted before being put into washing machine. As for the curtains with hooks, the hooks shall be removed before being washed.

The decorations on the clothes may damage the washing machine. As for the clothes with buttons or embroideries, they shall be turned over before being washed.

Clean up fasteners:



Zips shall be zipped close and buttons or hooks shall be fixed. The loose band or ribbon shall be bound together.

Important

It is suggested to put bras into the pillowslip with zip or buttons sealed to prevent the steel wire from popping out of bras into the drum and damaging the machine.

Especially delicate textiles such as laced curtains, straightjackets, small articles (tight socks, handkerchiefs, ties etc.) shall be put into string bag for washing.

When washing a single big and heavy dress such as Turkish towels, jeans, wadded jackets etc., it may easily cause great eccentricity and give alarm due to great unbalance. Therefore it is suggested to add one or two more clothes to be washed together so that draining can be done smoothly.

**Clean away dusts, stains and pet hairs from the clothes.**

The clothes may be damaged and disturb washing effects during the friction between dusts, stains and clothes.

To protect baby skin

Baby articles (baby clothes and towels) including napkins shall be washed separately.

If they are washed together with the adults' clothes, they may be infected. Rinsing times shall be increased to ensure the thorough rinsing and cleaning without the detergent residues.

It is suggested that the parts that are easily stained such as white sockets, collars and sleeves etc. shall be hand washed before being put into washing machine to achieve more ideal washing effects.

Please use powder or liquid detergents. The residues of the soap could remain in the gaps of the clothes if soap is used.

Confirm the washing capacity:

Do not put excessive washings; otherwise it may affect the washing effects. Please confirm the maximum affordable washing quantity according to the following table.

Fiber Type	Maximum Loading Capacity			
	6,0 kg	7,0 kg	8,0 kg	10,0 kg
Cotton	6 kg	7 kg	8 kg	10 kg
Synthetics	3 kg	3,5 kg	4 kg	5 kg
Wool	2 kg	2 kg	2 kg	2 kg
Silk	2,5 kg	2,5 kg	2,5 kg	2,5 kg

The clothes which easily get fuzzed shall be turned over for washing

The clothes which easily get fuzzed shall be washed separately; otherwise the other articles can be stained with dust and thrum etc. Preferably, black clothes and cotton clothes shall be washed separately because they can easily get stained with the thrums of other colors when being washed together.

Please check before washing.

Washing machine shall not wash water-proof materials (ski suits, outside napkin pads, curtains).

As for the fiber products that water can not get soaked easily into such as water-proof cushions, and clothes, it is better not to wash. Otherwise there will be water bursting out or abnormal vibration to cause danger while rinsing and draining so that the clothes also may be damaged. (Such as outside napkin pads, raincoats, umbrella, ski suits, car covers, sleeping sacks etc.)

Cautions during Draining


Draining of normal clothes:

Moistures of washings are drained through drain hole.

Draining of water-proof clothes and fiber products:

In the normal washing and draining status, moistures of water-proof clothes and fiber products can not be drained while washing water is gathered in one direction so that the eccentricity of washing machine is too great and vibration or moving is caused.


Quick Start



AFTER WASHING NOTES:

1. **After washing, the washing machine will make the sound;**
2. **Close the water tap;**
3. **Press the power and pull out the power plug.**

View of Control Panel



NOTES

1. The Control panel line chart is for reference only, Please refer to real product as standard.
2. The Control panel could be changed without written notice. Please visit the website of Washing Machine or call up the service line for consultation.
3. When the lights of Speed (600, 800, 1 000, 1 200, 1 400, 1 600) are off means the speed is 0.



"The wool wash cycle of this machine has been approved by The Woolmark Company for the washing of machine washable wool products provided that the products are washed according to the instructions on the garment label and those issued by the manufacturer of this washing machine. PLD 1483 Crown: M14161 ; PLDS 1483 Crown: M14162 ; PLD 16106 Crown: M1529."

The Woolmark is only available for Model PLD 1483 Crown and PLDS 1483 Crown and PLD 16106 Crown.

Washing Clothes at first time

Before washing clothes at first time, the washing machine shall be operated in one round of the whole procedures without clothes in as follows:

1. Connect power source and water.
2. Put a little detergent into the box and close it.
3. Press the button "On/Off".
4. Press the button "Start/Pause".

The drawer is separated as follows:

I: Pre-detergent or washing powder.

II: Main detergent

☼: Washing additive, such as fabric softener or tackifier.

Put detergent into washing machine.

1. Pull out the drawer.
2. Fill pre-detergent into Case I (when necessary).
3. Fill detergent into Case II.
4. Fill softener into Case ☼ (when necessary).

NOTES:

- ***As for the agglomerated or ropy detergent or additive, before they are poured into the detergent box, it is suggested to use some water for dilution to prevent the inlet of detergent box from being blocked and overflowing while filling water.***
- ***Please choose suitable type of detergent for the various washing temperature to get the best washing effect with less water and energy consumption.***

Start up washing machine

Connect the power. Check if water pipes are connected properly. Open the tap completely.

Put in the clothes to be washed and fill in the detergent and tackifier. Then press the button "On/Off", Select the proper procedures and functions and press the button "Start/Pause".

Select the procedure

The proper washing procedures shall be selected according to the types, quantities, and dirtiness of the clothes to be washed in combination with the following washing temperature table.

90 °C	Seriously besmirched, pure white cotton or flax (for example: coffee table cloths, canteen table cloths, towels, bed sheets)
60 °C	Moderately besmirched, colorful flax, cotton and synthetic articles with certain decolorizing degree (for example: shirts, night pajamas; Slightly besmirched, pure white flax)
40 °C, 30 °C, 30 °C Cold water	Normally besmirched articles (for example: synthetic and wool)

First, turn the rotary switch to select the corresponding procedures according to the types of textiles.
Second, select the proper temperature according to the dirtiness. Generally, the higher the temperature is, the more the power is consumed.
Last, select the proper revolution speed. The higher the revolution speed is, the drier the textiles are spun, but higher the noises will also be increased.
The surfaces of delicate textiles will have wrinkles and the working life of washing machine will be shortened.
PLEASE NOTE: to protect the clothes, the lower revolution speed shall be selected for delicate textiles. The main washing procedures depend on the types of the clothes to be washed as follows:

- **Cotton**

You can select this procedure to wash the daily washable clothes. The washing period is quite long with quite strong washing intension. It is recommended to wash the daily cotton articles, for example: bed sheets, quilt covers, pillowcases, gowns, underwear etc.

- **Cotton ECO**

To increase the washing effects, main additional washing time is increased.

It is recommended to wash the clothes for babies or worn by the persons with allergic skin.

- **Synthetic**

You can select this procedure to wash the quite delicate clothes. The procedure is shorter compared with that for cottons and the washing intension is quite gentle. It is recommended to wash synthetic articles, for example: shirts, coats, blending. As for curtains and laced textiles, the procedure "Synthetic " shall be selected. While washing the knitting textiles, detergent quantity shall be reduced due to its loose string construction and easily forming bubbles.

- **Delicate**

You can select this procedure to wash your delicate clothes. Its washing intension is gentler and revolution speed is less compared with the procedure "Synthetic". It is recommended for the articles to be washed softly.

- **Wool**

You can select this procedure to wash the wool textiles labeled with "Machine Wash".

Please select the proper washing temperature according to the label on the articles to be washed. Furthermore, the proper detergent shall be selected for wool textiles.

- **Baby Care**

Baby care procedure with an extra rinse, it can make the baby's wear cleaner and make the rinse performance better to protect the baby skin.

- **Colors**

You can choose the program washing brightly colored clothing, it can protect the bright colors better .

- **Quick**

This procedure is suitable for washing few and not very dirty clothes quickly.

- **Spin Only**

Separate spin only procedure. Soap water or rinse water shall be drained out before spinning.

- **Rinse&Spin**

Separate Rinse&Spin Procedure.

- **Drain Only**

Separate Drain only Procedure.

- **Mix**

You can select this procedure wash the tough clothes, that need much more time and strength. It is used for the daily clothes fo cotton, such as sheets, chained, pillowcases bathrobe and underwear.

- **Sport Wear**

You can select this procedure to wash the activewear.

- **Jeans**

This program is specially designed for washing jeans.

- **Hand Wash**

As for few light dirty clothes, the default temperature of washing is cold.

The main function can be selected as follows:

- **Prewash**

The Prewash function can get an extra wash before main wash.

- **Speed Wash**

The function can decrease the washing time.

- **Extra Rinse**

The laundry will undergo extra rinse once after you select it.

- **Delay**

Delay function can be set with this button, the delaying the time is 0-24h.

Set the delay function:

1. Select a procedure;
2. Press the Delay button choose the time;
3. Press Start/Pause to commence the Delay operation.

Cancel the Delay function:

Press the Delay button until the display will to be 0h.

Notes: If there is any break in the power supply while the machine is operating, a special memory stores the selected programme and when the power is restored, it continues where it left off.

- **Reload**

This operation can be executed during the washing procedure. When the drum of the washing machine is still rolling and there is large amount of water with high temperature in the drum. The state is unsafe and the door cannot be opened forcefully. To press ddd Start/Pause eee for 3 sec. to reload, and start the clothes adding in the midway function.

Please follow the steps as bellow:

1. Wait until the drum stops rotation.
2. The door lock is unlocked.
3. Close the door when the clothes needs are loaded and repress the «Start/Pause». button.

- **Child Lock**

To avoid that the washing procedure cannot operate normally due to the mis operation by kids during the washing procedure, you can select this function, In this case, the other buttons except On/Off button can not work, at this state ,the machine power off when press the key on/off. The machine remembers the program child lock and the program during powered off when press the key on/off again.

Press Rinse and Pre Wash together 2.5 seconds during the running procedure, the buzzer will beep ,Start/ Pause button as well as the rotary switch are locked. Press the two buttons for 2.5 seconds together and buzzer will beep to release to locking. But cut off the power supply, the kid's protection is also release to locking. The kid's protection will not be cancelled after all procedures are completed.

- **Bubble Removal Function**

Bubble Check Function: Redundant bubbles will occur when there is excessive detergent, which will affect wash and rinse effects. The procedure will check automatically and one bubble removal procedure will be added automatically to remove bubbles when excessive bubbles are checked.

Operate Washing Machine

Procedure Description	Load (kg)			Detergent Box			Delay	Speed wash	Extra rinse	Prewash	Default TEMP (°C)	Default Time (Min)						Default Speed (RPM)		
	6.0	7.0	8.0	Case I	Case II	Softener Case						1000	6.0 kg		7.0/8.0 kg		1000	1200	1400	
Cotton	6.0	7.0	8.0	○	●	○	○	○	○	○	40	2:40	2:40	2:40	2:40	2:40	2:40	800	800	800
Synthetic	3.0	3.5	4.0	○	●	○	○	○	○	○	40	1:40	1:40	1:40	1:40	1:40	1:40	800	800	800
Baby Care	6.0	7.0	8.0	○	●	○	○	○	○	○	30	1:20	1:20	1:20	1:20	1:20	1:20	800	800	800
Jeans	6.0	7.0	8.0	○	●	○	○	○	○	○	60	1:45	1:45	1:45	1:45	1:45	1:45	800	800	800
Mix	6.0	7.0	8.0	○	●	○	○	○	○	○	40	1:13	1:13	1:13	1:13	1:13	1:13	800	800	800
Colors	3.0	3.5	4.0	X	●	○	○	○	○	X	Cold	1:10	1:10	1:10	1:10	1:10	1:10	800	1000	1000
Drain Only	-	-	-	X	X	X	○	X	X	X	-	0:01	0:01	0:01	0:01	0:01	0:01	-	-	-
Spin Only	6.0	7.0	8.0	X	X	X	○	X	X	X	-	0:12	0:12	0:12	0:12	0:12	0:12	800	800	1000
Rinse&Spin	6.0	7.0	8.0	X	X	○	○	X	○	X	-	0:20	0:20	0:20	0:20	0:20	0:20	800	800	1000
Wool	2.0	2.0	2.0	X	●	○	○	○	X	X	40	1:07	1:07	1:07	1:07	1:07	1:07	600	600	600
Delicate	2.5	2.5	2.5	X	●	○	○	○	○	X	30	0:50	0:50	0:50	0:50	0:50	0:50	600	600	600
Quick	2.0	2.0	2.0	X	●	○	○	○	X	X	Cold	0:15	0:15	0:15	0:15	0:15	0:15	800	800	800
Sport Wear	3.0	3.5	4.0	○	●	○	○	○	X	○	40	0:45	0:45	0:45	0:45	0:45	1000	1200	1200	1200
Hand Wash	2.0	2.0	2.0	○	●	○	○	○	X	○	Cold	1:00	1:00	1:00	1:00	1:00	600	600	600	600
Cotton ECO	6.0	7.0	8.0	X	●	○	○	○	X	X	60	2:53	2:56	2:51	2:58	2:53	1000	1200	1400	1400

The energy class is A+++ Energy test program: Cotton ECO 60/40 °C, Speed: the highest speed; Other as the default.

„Cotton ECO 60/40°C“ are the „standard Cotton 60/40°C“ programme and the standard washing programs to which the information in the label and the fiche relates, and they are suitable to clean normally soiled cotton laundry and that they are the most efficient programmes in terms of combined energy and water consumptions for washing that type of cotton laundry, that the actual water temperature may differ from the declared cycle temperature.

● Means must ○ Means optional X Means not necessary

Notes: The parameters in this table are only for user's reference. The actual parameters maybe different with the parameters in above mentioned table.

Procedure Description	Load (kg)		Detergent Box			Delay	Speed wash	Extra rinse	Prewash	Default TEMP (°C)	Default Time (Min)		Default Speed (RPM)	
	"8.0 Slim"	"10.0 "	Case I	Case II	Softener Case						8.0 kg	10.0 kg	1400	1600
Cotton	8.0	10.0	○	●	○	○	○	○	○	40	2:40	2:40	800	800
Synthetic	4.0	5.0	○	●	○	○	○	○	○	40	1:40	1:40	800	800
Baby Care	8.0	10.0	○	●	○	○	○	○	○	30	1:20	1:20	800	800
Jeans	8.0	10.0	○	●	○	○	○	○	○	60	1:45	1:45	800	800
Mix	8.0	10.0	○	●	○	○	○	○	○	40	1:13	1:13	800	800
Colors	4.0	5.0	X	●	○	○	○	○	X	Cold	1:10	1:10	1000	1200
Drain Only	-	-	X	X	X	○	X	X	X	-	0:01	0:01	-	-
Spin Only	8.0	10.0	X	X	X	○	X	X	X	-	0:12	0:12	1000	1200
Rinse&Spin	8.0	10.0	X	X	○	○	X	○	X	-	0:20	0:20	1000	1200
Wool	2.0	2.0	X	●	○	○	X	○	X	40	1:07	1:07	600	800
Delicate	2.5	2.5	X	●	○	○	X	○	X	30	0:50	0:50	600	800
Quick	2.0	2.0	X	●	○	○	X	X	X	Cold	0:15	0:15	800	800
Sport Wear	4.0	5.0	○	●	○	○	X	○	○	40	0:45	0:45	1200	1200
Hand Wash	2.0	2.0	○	●	○	○	X	○	○	Cold	1:00	1:00	600	800
Cotton ECO	8.0	10.0	X	●	○	○	X	X	X	60	"2:59 3:57 (Bldc)"	3:59	1400	1600

The energy class is A+++ Energy test program: Cotton ECO 60/40 °C, Speed: the highest speed; Other as the default.

Half amount of 8 kg / 10 kg are 4 kg / 5 kg.

„Cotton ECO 60/40°C“ are the „standard Cotton 60/40°C“ programme and the standard washing programs to which the information in the label and the fiche relates, and they are suitable to clean normally soiled cotton laundry and that they are the most efficient programmes in terms of combined energy and water consumptions for washing that type of cotton laundry, that the actual water temperature may differ from the declared cycle temperature.

● Means must ○ Means optional X Means not necessary

Notes: The parameters in this table are only for user's reference. The actual parameters may be different with the parameters in above mentioned table.

PART 5: MAINTENANCE

Before your maintenance starts, please do pull out the power plug or disconnect power and close the tap.

WARNING:

- **Solvents are forbidden to avoid that the washing machine is damaged, and toxic gases are generated or exploded.**
- **Never use water to sprinkle and wash the washing machine.**
- **It is forbidden that the detergents containing PCMX are used to clean the washing machine.**

Cleaning and Maintenance of Washing Machine Cabinet

Proper maintenance on the washing machine can extend its working life. The surface can be cleaned with diluted non-abrasive neutral detergents when necessary. If there is any water overflow, use the wet cloth to wipe it off immediately. No sharp items are allowed to strike the cabinet.

NOTE:

Formic acid and its diluted solvents or equivalent are forbidden.

Clean Internal Drum

The rusts left inside the drum by the metal articles shall be removed immediately with chlorine-free detergents. Never use steel wool.

Dispose a Frozen Washing Machine

When the temperature drops below zero and your washing machine gets frozen, you may:

1. Disconnect the power supply for the washing machine.
2. Wash the tap with warm water to loosen inlet pipe.
3. Take down inlet pipe and immerse it in warm water.
4. Pour warm water into washing drum and wait for 10 minutes.
5. Reconnect inlet pipe to the tap and check whether inlet and outlet are working normally.

NOTE:

When the washing machine is reused, make sure the ambient temperature is above 0 °C


Anti-freeze

If your washing machine is located in the room where it can get frozen easily, please drain the remaining water inside drain pipe and inlet pipe thoroughly.

Remove the remaining water in inlet pipe:

1. Close the tap.
2. Screw off the inlet pipe from tap and put its end into the container.
3. Start up any procedure except single Wash or Drain procedure. Water will be drained out of inlet pipe if any for about 40 seconds.
4. Reconnect the inlet pipe to tap.

Remove the remaining water in drain pump






WARNING:

To avoid burning, it shall be done after the hot water inside the machine cools down.

Clean detergent box and grooves

Clean detergent drawer and grooves

1. Press down the arrow location on softener cover inside the drawer.
2. Lift the clip up and take out softener cover and wash all grooves with water.
3. Restore the softener cover and push the drawer into position.



Clean inlet filter

Inlet filter shall must be cleaned if there is not any or insufficient water in when the tap is opened.

Clean the tap filter:

1. Close the tap.
2. Select any procedure except "Wash" or "Drain" procedure.
3. Press the button "Start/Pause" and keep the procedure running for about 40 seconds.
4. Remove the inlet pipe from the tap.
5. Use water to wash the filter.
6. Reconnect the inlet pipe.




Washing the filter in washing machine:

1. Screw off the inlet pipe from the backside of the machine.
2. Pull out the filter with long nose pliers and reinstall it back after being washed.
3. Reconnect the inlet pipe.
4. Open the tap and make sure there is no water leakage.
5. Close the tap.

NOTE:

Generally, the tap filter is washed first and then the filter in washing machine will be washed.

If only the filter in washing machine is washed, then the steps 1~3 in cleaning the tap filter shall be repeated.



WARNING:

Pull out the power plug to avoid electrical shock before washing.

After using the washing machine, pull out the power cord and close the door tightly to avoid pinching the kids.

Remove foreign matters

Drain Pump Filter:

Drain pump filter can filter the yarns and small foreign matters from the washings.

Clean the filter periodically to ensure the normal operation of washing machine.

WARNING:

First, drain the water with drain pump and then open the drain pump to clean away foreign matters from drain pump filter. Take care if the drained water is hot.


Cleaning the pump

Important


According to the soil level within the cycles and the frequency of the cycles, you have to inspect and clean the filter regularly.

The pump should be inspected if the machine does not empty and/or spin; the machine makes an unusual noise during draining due to objects such as safety pins, coins etc. blocking the pump.


Proceed as follows:




Open
the service panel



Unscrew
the pump cover



Remove
the pump cover



Close
the service panel

- 1 Disconnect the appliance.
- 2 If necessary wait until the water has cooled down.
- 3 Open the service panel .Place a container close to collect any spillage.
- 4 When no more water comes out, unscrew the pump cover and remove it.
Always keep a rag nearby to dry up spillage of water when removing the cover.
- 5 Remove any objects from the pump impeller by rotating it.
- 6 Screw the pump cover fully in.
- 7 Close the service panel.

WARNING:

When the appliance is in use and depending on the programme selected there can be hot water in the pump. Never remove the pump cover during a wash cycle, always wait until the appliance has finished the cycle, and is empty. When replacing the cover, ensure it is securely retightend so as to stop leaks and young children being able to remove it.

Troubleshooting

Troubles	Reason	Solution
Washing machine cannot start up		Check if the door is closed tightly. Check if power plug is inserted well. Check if water supply tap is opened. Check if button "Start/Pause" is pressed. Check if button "On/Off" is pressed.
Door cannot be opened	Machine's safety protection design is working.	Disconnect the power.
Heating fault	NTC is damaged and heating pipe is aging.	Can normally wash the clothes. Only cannot wash with heating. Shall contact the service center promptly.
Water leakage	The connection between inlet pipe or outlet hose and tap or washing machine is not tight. Drain pipe in the room is blocked.	Check and fasten water pipes. Clean up outlet hose and ask a specialized person to repair it when necessary.
Water is overflowed from the bottom of the machine	The inlet pipe is not connected firmly. Outlet hose has water leakage.	Fix the inlet pipe. Replace the drain hose.
Indicator or display does not light.	Power is disconnected. PC board has problems. Harness has connection problem.	Check if the power is shut down and power plug is connected correctly. If not, please call up service line.
Detergent residues in the box	Washing powder is dampened and agglomerated.	Clean and wipe the box. Use liquid detergents or the detergents special for drum.
Washing effects are not good	The clothes are too dirty. Insufficient detergent quantity.	Check if the fixing (bolts) has been removed. If cabinet is installed on the solid and level floor.
Abnormal noise Great vibration		Check if there are any barrettes or metal articles inside. Check if the legs in the washing machine are adjusted level.












Remove the problems













Display LED	Description	Reason	Solution
E30	Door lock problem	Door is not closed properly.	Restart after the door is closed.
		Please call up service line if there are still troubles.	
E10	Water injecting problem while washing	Tap is not opened or water flows too slowly. Inlet valve filter is blocked. Inlet pipe is twisted. If water is not supplied	Open the tap or wait till the water supply becomes normal. Check inlet valve filter. Straighten the water pipe Check the other taps in the room.
		Please call up service line if there are still troubles.	
E21	Drain problem while washing	Outlet hose is blocked or twisted Drain pump is blocked	Wash and straighten outlet hose. Wash drain pump filter
		Please call up service line if there are still troubles.	
Please call up the service line if there is any other problem.			










PART 6: APPENDIX

Care Lable

The label and sign on the fabric can help you to choose the best way to launder your clothes.

Normal wash  Gentle wash 	 Warm wash (max 40°C)	Hand wash  Do not wash 	Bleach  Do not bleach 	Chlorine bleach may be used  Chlorine bleach not be used 	Tumble dry. Medium (max 150°C)  Tumble dry. Low heat (max 110°C) 
--	--	--	---	--	--

Iron  Do not iron 	Cool iron (max 110 °C)  Warm iron. medium (max 150°C) 	Dry clean  Do not dry clean 	Dry clean normal cycle with any solvent   Dry clean normal cycle petroleum solvent only	Tumble dry normal  Dry flat 	Drip dry  Hang to dry/ Line dry 
---	---	---	--	--	--

Iron with cloth  Steam Iron 	Dry after wash  Line Dry in shade 	Warmly dry clean  Do not tumble dry 	 Line Dry	 No Wring	 No machine wash
---	--	---	---	--	---

ELECTRICAL WARNING

To avoid fire, electrical shock and other accidents, please remember the following reminding:

- Only the voltage indicated in power label can be used. If you are not clear of the voltage at home, please contact the local power bureau.
- When you are using the heating function, the maximum current through the washing machine will reach 10 A. Therefore, please make sure the power supply units (current, voltage and cable) can meet the normal load requirements for the machine.
- Protect the power cord properly. Power cord shall be fixed well so that it will not trip the people or other things and be damaged. Special attention shall be paid to the socket. It shall be plugged into the sockets easily and attention shall be paid to the plug location.
- Do not make the wall-mounted socket overloaded or cable extended. Overloading of the wiring may cause fire or electrical shock. Do not pull out power plug with wet hand.
- To ensure your safety, power plug shall be inserted into an earthed three-pole socket. Carefully check and ensure that your socket is properly and reliably earthed.

Product Specifications

Model	PLD 1273 Crown	PLD 1483 Crown	PLD 16106 Crown
Washing Capacity	7.0 kg	8.0 kg	10,0 kg
Dimension (W*D*H)	595 x 495 x 850	595 x 565 x 850	595 x 565 x 850 mm
Net Weight	61 kg	68 kg	70 kg
Rated Power	2050 W	2000 W	2000 W
Power Supply	220-240V~, 50Hz	220-240V~, 50Hz	220 -240 V~, 50 Hz
MAX. Current	10 A	10 A	10 A
Standard Water Pressure	0.05 MPa ~ 1 MPa	0.05 MPa ~ 1 MPa	0,05 MPa - 1 MPa

Model	PLDS 1263 Crown / PLDS 1063 Crown	PLDS 1483 Crown
Washing Capacity	6.0 kg (SLIM)	8,0 kg (Slim)
Dimension (W*D*H)	595 x 470 x 850	595 x 470 x 850 mm
Net Weight	56 kg	63 kg
Rated Power	2000 W	2000 W
Power Supply	220-240V~, 50Hz	220 -240 V~, 50 Hz
MAX. Current	10 A	10 A
Standard Water Pressure	0.05 MPa ~ 1 MPa	0,05 MPa - 1 MPa

PART 7: INFORMATION SHEET

Information Sheet INFORMATION SHEET: Philco

Philco brand: **PHILCO** 

Brand	Philco					
Product number	PLD 16106 Crown	PLD 1483 Crown	PLD 1273 Crown	PLDS 1483 Crown	PLDS 1263 Crown	PLDS 1063 Crown
Washing capacity (kg) - cotton 60 °C	10	8	7	8	6	6
Energy efficiency class (A... low electricity consumption to G high electricity consumption) for washing, spinning, drying per single cycle	A+++	A+++	A+++	A+++	A+++	A+++
Annual power consumption (kWh) cotton - 60 °C *	167	196	175	196	153	153
Power consumption (kWh) - cycle 60 °C, 60 °C / 40 °C half load	0,77/0,77/0,66	1.05/0.84/0.63	0.93/0.80/0.51	0.97/0.98/0.66	0.79/0.64/0.54	0.79/0.64/0.54
Power consumption in turned off state W	0,5	0,5	0,5	0,5	0,5	0,5
Power consumption in turned on state W	1	1	1	1	1	1
Annual water consumption (l) - washing, drying - cotton 60 °C *	13000	11 000	10000	11 000	9240	9240
Spinning class	A	B	B	B	B	C
Maximum rpm (washing)	1600	1400	1200	1400	1200	1000
Standard program duration (min) - cotton 60 °, 60 ° / 40 °C half load	239/239/233	179/179/179	179/179/179	179/179/174	179/179/179	179/179/179
Airborne noise dB (re 1pW) ** - washing	56	59	59	59	59	59
Operation	free standing	free standing	free standing	free standing	free standing	free standing
Airborne noise dB (re 1pW) ** - spinning	78	78	76	78	76	74
Dimensions cm (h x w x d) cm	85 x 59,5 x 56,5	85 x 59,5 x 56,5	85 x 59,5 x 49,5	85 x 59,5 x 47	85 x 59,5 x 47	85 x 59,5 x 47
Weight kg	70	68	61	63	56	56

The standard program for washing cotton at 60 °C is the standard washing program, to which the information contained on the rating label relates. This program is suitable for washing standard soiled cotton laundry and is the most effective program in terms of the combined water and power consumption.

* The annual water and power consumption based on 220 standard wash cycles using the for cotton at 60 °C and 40 °C at full and half load and power mode with low power consumption Actual power consumption will depend on how the appliance is used.

** Noise level according to European norm EN 60704

The program configuration for testing is in accordance with standard EN 60456-2011.

NOTE:

All the here mentioned data is subject to change.

The household washing machine is equipped with power management system.
The duration of the left-on mode time is less than 1 minute.

INSTRUCTIONS AND INFORMATION REGARDING THE DISPOSAL OF USED PACKAGING MATERIALS

Dispose of packaging material at a public waste disposal site.

DISPOSAL OF USED ELECTRICAL AND ELECTRONIC APPLIANCES



The meaning of the symbol on the product, its accessory or packaging indicates that this product shall not be treated as household waste. Please, dispose of this product at your applicable collection point for the recycling of electrical & electronic equipment waste. Alternatively in some states of the European Union or other European states you may return your products to your local retailer when buying an equivalent new product. The correct disposal of this product will help save valuable natural resources and help in preventing the potential negative impact on the environment and human health, which could be caused as a result of improper liquidation of waste. Please ask your local authorities or the nearest waste collection centre for further details. The improper disposal of this type of waste may fall subject to national regulations for fines.

For business entities in the European Union

If you wish to dispose of an electrical or electronic device, request the necessary information from your seller or supplier.

Disposal in other countries outside the European Union

If you wish to dispose of this product, request the necessary information about the correct disposal method from local government departments or from your seller.



This product meets all the basic EU regulation requirements that relate to it.

Changes to the text, design and technical specifications may occur without prior notice and we reserve the right to make these changes.

The original version is in the Czech language.

Address of the manufacturer: FAST ČR, a.s., Černokostelecká 1621, Říčany CZ-251 01.

NOTES