

**INDUCTION
GLASS-CERAMIC HOB
OWNER'S MANUAL**

PHILCO



Famous for Quality the World Over

**PHD 61FS
PHD 62FS**

**Dear customer,
Thank you for buying a PHILCO brand product. So that your appliance serves you well, please read all the instructions in this user's manual.**

Dear customer,

Thank you for having chosen a induction hob.

In order to install properly your appliance and to make the best use of it, please read this entire instruction manual carefully.

CONTENTS

PART 1: SAFETY INFORMATION.....	2
PART 2: DESCRIPTION OF THE APPLIANCE	7
Technical characteristics.....	7
Control panel.....	8
PART 3: USE OF THE APPLIANCE	8
Display.....	8
Ventilation.....	8
PART 4: STARTING-UP AND APPLIANCE MANAGEMENT	9
Before the first use.....	9
Induction principle.....	9
Sensitive touch.....	9
Starting-up.....	9
Pan detection.....	10
Residual heat indication.....	10
Booster and double booster function.....	10
Timer.....	11
Bridge Function.....	12
Control panel locking.....	12
PART 5: COOKING ADVICES	13
Pan quality.....	13
Pan dimension.....	13
Examples of cooking power setting.....	14
PART 6: MAINTENANCE AND CLEANING.....	14
PART 7: WHAT TO DO IN CASE OF A PROBLEM	15
PART 8: INSTALLATION INSTRUCTIONS	17
PART 9: ELECTRICAL CONNECTION	18
Connection of the hob.....	18



This appliance has been tested in accordance with the directives in force in the European Union.
This appliance conforms to the relevant safety provisions for electrical appliances in force in the European Union.

PART 1: SAFETY INFORMATION

PRECAUTIONS BEFORE USING

- UNPACK ALL THE MATERIALS.
- THE INSTALLATION AND CONNECTING OF THE APPLIANCE HAVE TO BE DONE BY APPROVED SPECIALISTS. THE MANUFACTURER CANNOT BE RESPONSIBLE FOR DAMAGE CAUSED BY BUILDING-IN OR CONNECTING ERRORS.
- TO BE USED, THE APPLIANCE MUST BE WELL-EQUIPPED AND INSTALLED IN A KITCHEN UNIT AND AN ADAPTED AND APPROVED WORK SURFACE.
- THIS DOMESTIC APPLIANCE IS EXCLUSIVELY FOR THE COOKING OF FOOD, TO THE EXCLUSION OF ANY OTHER DOMESTIC, COMMERCIAL OR INDUSTRIAL USE.
- REMOVE ALL LABELS AND SELF-ADHESIVES FROM THE CERAMIC GLASS.
- DO NOT CHANGE OR ALTER THE APPLIANCE.
- THE COOKING PLATE CANNOT BE USED AS FREESTANDING OR AS WORKING SURFACE.
- THE APPLIANCE MUST BE GROUNDED AND CONNECTED CONFORMING TO LOCAL STANDARDS.
- DO NOT USE ANY EXTENSION CABLE TO CONNECT IT.
- THE APPLIANCE CANNOT BE USED ABOVE A DISHWASHER OR A TUMBLER DRYER:
STEAM MAY DAMAGE THE ELECTRONIC APPLIANCES.

- THE APPLIANCE IS NOT INTENDED TO BE OPERATED BY MEANS OF EXTERNAL TIMER OR SEPARATE REMOTE CONTROL SYSTEM.
- CAUTION : THE COOKING PROCESS HAS TO BE SUPERVISED. A SHORT TERM COOKING PROCESS HAS TO BE SUPERVISED CONTINUOUSLY.

USING THE APPLIANCE

- SWITCH THE HEATING ZONES OFF AFTER USING.
- KEEP AN EYE ON THE COOKING USING GREASE OR OILS: THAT MAY QUICKLY IGNITE.
- BE CAREFUL NOT TO BURN YOURSELF WHILE OR AFTER USING THE APPLIANCE.
- MAKE SURE NO CABLE OF ANY FIXED OR MOVING APPLIANCE CONTACTS WITH THE GLASS OR THE HOT SAUCEPAN.
- MAGNETICALLY OBJECTS (CREDIT CARDS, FLOPPY DISKS, CALCULATORS) SHOULD NOT BE PLACED NEAR TO THE ENGAGED APPLIANCE.
- METALLIC OBJECTS SUCH AS KNIVES, FORKS, SPOONS AND LIDS SHOULD NOT BE PLACED ON THE HOB SURFACE SINCE THEY CAN GET HOT.
- IN GENERAL DO NOT PLACE ANY METALLIC OBJECT EXCEPT HEATING CONTAINERS ON THE GLASS SURFACE. IN CASE OF UNTIMELY ENGAGING OR RESIDUAL HEAT, THIS ONE MAY HEAT, MELT OR EVEN BURN.
- NEVER COVER THE APPLIANCE WITH A CLOTH OR A PROTECTION SHEET. THIS IS SUPPOSED TO BECOME VERY HOT AND CATCH FIRE.

- THIS APPLIANCE CAN BE USED BY CHILDREN AGED FROM 8 YEARS AND ABOVE AND PERSONS WITH REDUCED PHYSICAL, SENSORY OR MENTAL CAPABILITIES OR LACK OF EXPERIENCE AND KNOWLEDGE IF THEY HAVE BEEN GIVEN SUPERVISION OR INSTRUCTION CONCERNING USE OF THE APPLIANCE IN A SAFE WAY AND UNDERSTAND THE HAZARDS INVOLVED.
- CHILDREN SHALL NOT PLAY WITH THE APPLIANCE.
- CLEANING AND USER MAINTENANCE SHALL NOT BE MADE BY CHILDREN WITHOUT SUPERVISION.

PRECAUTIONS NOT TO DAMAGE THE APPLIANCE

- RAW PAN BOTTOMS OR DAMAGED SAUCEPANS (NOT ENAMELLED CAST IRON POTS,) MAY DAMAGE THE CERAMIC GLASS.
- SAND OR OTHER ABRASIVE MATERIALS MAY DAMAGE CERAMIC GLASS.
- AVOID DROPPING OBJECTS, EVEN LITTLE ONES, ON THE VITROCERAMIC.
- DO NOT HIT THE EDGES OF THE GLASS WITH SAUCEPANS.
- MAKE SURE THAT THE VENTILATION OF THE APPLIANCE WORKS ACCORDING TO THE MANUFACTURER'S INSTRUCTIONS.
- DO NOT PUT OR LEAVE EMPTY SAUCEPANS ON THE VITROCERAMIC HOBS.
- SUGAR, SYNTHETIC MATERIALS OR ALUMINIUM SHEETS MUST NOT CONTACT WITH THE HEATING ZONES. THESE MAY CAUSE BREAKS OR OTHER ALTERATIONS OF THE VITROCERAMIC GLASS BY COOLING: SWITCH ON THE APPLIANCE AND TAKE THEM IMMEDIATELY OUT OF THE HOT HEATING ZONE (BE CAREFUL: DO NOT BURN YOURSELF).

- **WARNING: DANGER OF FIRE: DO NOT STORE ITEMS ON THE COOKING SURFACE.**
- **NEVER PLACE ANY HOT CONTAINER OVER THE CONTROL PANEL.**
- **IF A DRAWER IS SITUATED UNDER THE EMBEDDED APPLIANCE, MAKE SURE THE SPACE BETWEEN THE CONTENT OF THE DRAWER AND THE INFERIOR PART OF THE APPLIANCE IS LARGE ENOUGH (2 CM). THIS IS ESSENTIAL TO GUARANTYA CORRECT VENTILATION.**
- **NEVER PUT ANY INFLAMMABLE OBJECT (EX. SPRAYS) INTO THE DRAWER SITUATED UNDER THE VITROCERAMIC HOB. THE EVENTUAL CUTLERY DRAWERS MUST BE RESISTANT TO HEAT.**

PRECAUTIONS IN CASE OF APPLIANCE FAILURE

- **IF A DEFECT IS NOTICED, SWITCH OFF THE APPLIANCE AND TURN OFF THE ELECTRICAL SUPPLYING.**
- **IF THE CERAMIC GLASS IS CRACKED OR FISSURED, YOU MUST UNPLUG THE APPLIANCE AND CONTACT THE AFTER SALES SERVICE.**
- **REPAIRING HAS TO BE DONE BY SPECIALISTS. DO NOT OPEN THE APPLIANCE BY YOURSELF.**
- **WARNING: IF THE SURFACE IS CRACKED, SWITCH OFF THE APPLIANCE TO AVOID THE POSSIBILITY OF ELECTRIC SHOCK. OTHER PROTECTIONS**

OTHER PROTECTIONS

- NOTE SURE THAT THE CONTAINER PAN IS ALWAYS CENTRED ON THE COOKING ZONE. THE BOTTOM OF THE PAN MUST HAVE TO COVER AS MUCH AS POSSIBLE THE COOKING ZONE.
- FOR THE USERS OF PACEMAKER, THE MAGNETIC FIELD COULD INFLUENCE ITS OPERATING. WE RECOMMEND GETTING INFORMATION TO THE RETAILER OR OF THE DOCTOR.
- DO NOT TO USE ALUMINIUM OR SYNTHETIC MATERIAL CONTAINERS: THEY COULD MELT ON STILL HOT COOKING ZONES.
- NEVER TRY TO EXTINGUISH A FIRE WITH WATER, BUT SWITCH OFF THE APPLIANCE AND THEN COVER FLAME E.G. WITH A LID OR A FIRE BLANKET.



THE USE OF EITHER POOR QUALITY POT OR ANY INDUCTION ADAPTOR PLATE FOR NON-MAGNETIC COOKWARE RESULTS IN A WARRANTY BREACH. IN THIS CASE, THE MANUFACTURER CANNOT BE HELD RESPONSIBLE FOR ANY DAMAGE CAUSED TO THE HOB AND/OR ITS ENVIRONMENT.

PART 2: DESCRIPTION OF THE APPLIANCE


Technical characteristics

Type	PHD61FS	PHD62FS
Total power	7400 W	7400 W
Energy consumption for the hob EChob**	172.3 Wh/kg	174.6 Wh/kg
Front left heating zone		
Minimum detection	Ø 210x190 mm	Ø 210x190 mm
Nominal power*	Ø 90 mm 2100 W	Ø 90 mm 2100 W
Booster power*	2300 / 3000 W	2300 / 3000 W
Standardised cookware category**	C	C
Energy consumption EC _{cw} **	177.6 Wh/kg	177.6 Wh/kg
Rear left heating zone		
Minimum detection	Ø 210x180 mm	Ø 210x190 mm
Nominal power*	Ø 90 mm 1600 W	Ø 90 mm 1600 W
Booster power*	1850 W	1850 W
Standardised cookware category**	B	B
Energy consumption EC _{cw} **	161.3 Wh/kg	161.3 Wh/kg
Rear right heating zone		
Minimum detection	Ø 215 mm	Ø 210x190 mm
Nominal power*	Ø 90 mm 2300 W	Ø 90 mm 2100 W
Booster power*	3000 W	2300/2300 W
Standardised cookware category**	C	C
Energy consumption EC _{cw} **	168.4 Wh/kg	177.6 Wh/kg
Front right heating zone		
Minimum detection	Ø 175 mm	Ø 210x190 mm
Nominal power*	Ø 90 mm 1100 W	Ø 90 mm 1600 W
Booster power*	1400 W	1850 W
Standardised cookware category**	A	A
Energy consumption EC _{cw} **	181.9 Wh/kg	181.9 Wh/kg

* The given power may change according to the dimensions and material of the pan.

** Calculated according to the method of measuring performance (EN 60350-2).

Control panel



PART 3: USE OF THE APPLIANCE

Display

Display	Designation	Function
0	Zero	The heating zone is activated.
1...9	Power level	Selection of the cooking level.
<u>U</u>	Pan detection	No pan or inadequate pan.
A	Heat accelerator	Automatic cooking
E	Error message	Electronic failure.
P	Booster	The boosted power is activated.
H	Residual heat	The heating zone is hot.
L	Locking	Control panel locking.
U	Keep warm	Maintain automatically of 70°C
	Pause	The hob is in pause
,,	Double Booster	The Double Booster is activated.

Ventilation

The cooling system operates continuously. He starts when turning on the hob and speeds up when the hob is used intensively. The cooling fan reduces its speed and stops automatically when the electronic circuit is cooled enough.

PART 4: STARTING-UP AND APPLIANCE MANAGEMENT

Before the first use

Clean your hob with a damp cloth, and then dry the surface thoroughly. Do not use detergent which risks causing blue-tinted colour on the glass surface.

Induction principle

An induction coil is located under each heating zone. When it is engaged, it produces a variable electromagnetic field which produces inductive currents in the ferromagnetic bottom plate of the pan. The result is a heating-up of the pan located on the heating zone.

Of course the pan has to be adapted:

- All ferromagnetic pans are recommended (please verify it thanks a little magnet): cast iron and steel pans, enamelled pans, stainless-steel pans with ferromagnetic bottoms...
- Are excluded: copper, pure stainless-steel, aluminium, glass, wood, ceramic, stoneware,...

The induction heating zone adapts automatically the size of the pan. With a too small diameter the pan doesn't work. This diameter is varying in function of the heating zone diameter.

If the pan is not adapted to the induction hob the display will show [U].

Sensitive touch

Your ceramic hob is equipped with electronic controls with sensitive touch keys. When your finger presses the key, the corresponding command is activated. This activation is validated by a control light, a letter or a number in the display and/or a "beep" sound.

In the case of a general use press only one key at the same time.

Starting-up

You must first switching on the hob, then the heating zone:

- **Start-up/ switch off the hob:**

Action	Control panel	Display
To start	Press key [0/I]	[0] are blinking
To stop	Press key [0/I]	Nothing or [H]

- **Start-up/ switch off a heating zone:**

Action	Control panel	Display
To choice the zone	Press display [0] selected	[0] and control light on
To set (adjust the power)	Slide on the "SLIDER" to the right or to the left	[1] to [9]
To stop	Slide to [0] on the "SLIDER" or press on [0]	[0] or [H]

If no action is made within 20 second the electronics returns in waiting position.

Pan detection

The pan detection ensures a perfect safety. The induction doesn't work:

- If there is no pan on the heating zone or if this pan is not adapted to the induction. In this case it is impossible to increase the power and the display shows [U]. This symbol disappears when a pan is put on the heating zone.
- If the pan is removed from the heating zone the operation is stopped. The display shows [U]. The symbol [U] disappears when the pan is put back to the heating zone. The cooking continues with the power level set before.

After use, switch the heat element off: don't let the pan detection [U] active.

Residual heat indication

After the switch off of a heating zone or the complete stop of the hob, the heating zones are still hot and indicates [H] on the display.

The symbol [H] disappears when the heating zones may be touched without danger.

As far as the residual heat indicators are on light, don't touch the heating zones and don't put any heat sensitive object on them. **There are risks of burn and fire.**

Booster and double booster function

The booster function [P] grants a boost of power to the selected heating zone.

If this function is activated the heating zones works during 10 minutes with an ultra high power.

The booster is foreseen for example to heat up rapidly big quantities of water, like nuddles cooking.

Start up / Stop the booster function:

Action	Control panel	Display
Zone selection	Press key [0] from the zone	[0] and control light on
Start up the booster	Press key [P]	[P]
Stop the booster	Slide on the "SLIDER" or press on [P]	[P] to [0] [9]

Power management :

The whole cooking hob is equipped to give a maximum amount of power. When the booster function is activated, and not to exceed the maximum power, the electronic system orders to reduce automatically the power level of an other heating zone. The display is blinking on [9] during a few seconds and then shows the maximum of power allowed ([6] or [8]).

Heating zone selected	The other heating zone: (example: power level 9)
[P] is displayed	[9] goes to [6] or [8] depending the type of zone

Timer

The timer is able to be used simultaneous with all heating zones and this with different time settings (from 0 to 99 minutes) for each heating zone.

- **Setting and modification of the cooking time:**

Example for 16 minutes at power 7:

<u>Action</u>	<u>Control panel</u>	<u>Display</u>
Zone selection	Press display [0]	[0] and control light on
Select the power level	Slide on the "SLIDER" to [7]	[7]
Select « Timer »	Press display [CL]	[00]
Set the units	Slide on the "SLIDER" to [6]	[0] fixed] [6 blinking]
Valid the units	Press display [06]	[0 blinking] [6 fixed]
Set the tens	Slide on the "SLIDER" to [1]	[1 blinking] [6 fixed]
Valid the tens	Press display [16]	[16]

The time is confirmed and the cooking starts.

- **To stop the cooking time:**

Example for 13 minutes at power 7:

<u>Action</u>	<u>Control panel</u>	<u>Display</u>
Zone selection	Press display [7] selected	[0] and control light on
Select « Timer »	Press key [13]	[13]
Deactivate the units	Slide on the "SLIDER" to [0]	[1 fixed] [0 blinking]
Valid the units	Press display [10]	[1 blinking] [0 fixed]
Deactivate the tens	Slide on the "SLIDER" to [0]	[0 blinking] [0 fixed]
Valid the tens	Press display [00]	[00]

- **Automatic stop at the end of the cooking time:**

As soon as the selected cooking time is finished the timer displays blinking [00] and a sound rings. To stop the sound and the blinking it is enough to press the key [00].

- **Egg timer function:**

Example for 29 minutes :

<u>Action</u>	<u>Control panel</u>	<u>Display</u>
Activate the hob	Press display [0/1]	Zone control lights are on
Select « Timer »	Press display [CL]	[00]
Set the units	Slide on the "SLIDER" to [9]	[0 fixed] [9 blinking]
Valid the units	Press display [09]	[0 blinking] [9 fixed]
Set the tens	Slide on the "SLIDER" to [2]	[2 blinking] [9 fixed]
Valid the tens	Press display [29]	[29]

After a few seconds the control light stops blinking.

As soon as the selected cooking time is finished the timer display will blink [00] and a sound rings. To stop the sound and the blinking it is enough to press the display [00]. The hob switches off.

Bridge Function

This function allows to use the 2 cooking zones at same time with the same features as a single cooking zone. Booster function isn't allowed.

Action	Control panel	Display
Activate the hob	Press display [0/1]	[0] to [9] or [H]
Activate the bridge	Press on the 2 cooking zones	[0] appears on the before Area
Increase bridge	Slide on the "SLIDER" [1 to 9] or keep warm key	[Π] on the rear zone.
Stop the bridge	Press on the 2 cooking zones	[0] or [H] on the 2 zones

Control panel locking

To avoid modifying a setting of cooking zones , in particular with within the framework of cleaning the control panel can be locked (with exception to the On/Off key [0/1]).

• Locking:

Action	Control panel	Display
Start	Press key [0/1]	[0] or [H] on displays
Hob locking	Press simultaneously [P] and [O]	No modification
	Re-press on display [0] from the right zone display	[L] on displays

• Unlocking:

Action	Control panel	Display
Start	Press key [0/1]	[L] on displays
In the 5 seconds after start:		
Unlocking the hob	Press simultaneously [P] and [L] from the right zone display	[0] or [H] on displays
	Press on key [P]	No light on the displays

PART 5: COOKING ADVICES

Pan quality

Adapted materials:

steel, enamelled steel, cast iron, ferromagnetic stainless-steel, aluminium with ferromagnetic bottom.

Not adapted materials:


aluminium and stainless-steel without ferromagnetic bottom, copper, brass, glass, ceramic, porcelain.

The manufacturers specify if their products are compatible induction.

To check if pans are compatibles :

- Put a little water in a pan placed on an induction heating zone set at level [9]. This water must heat in a few seconds.
- A magnet sticks on the bottom of the pan.

Certain pans can make noise when they are placed on an induction cooking zone. This noise doesn't mean any failure on the appliance and doesn't influence the cooking operating.



Pan dimension

The cooking zones are, until a certain limit, automatically adapted to the diameter of the pan.

However the bottom of this pan must have a minimum of diameter according to the corresponding cooking zone.

To obtain the best efficiency of your hob, please place the pan well in the centre of the cooking zone.

Examples of cooking power setting

(the values below are indicative)

1 to 2	Melting Reheating	Sauces, butter, chocolate, gelatine Dishes prepared beforehand
2 to 3	Simmering Defrosting	Rice, pudding, sugar syrup Dried vegetables, fish, frozen products
3 to 4	Steam	Vegetables, fish, meat
4 to 5	Water	Steamed potatoes, soups, pasta, fresh vegetables
6 to 7	Medium cooking Simmering	Meat, liver, eggs, sausages Goulash, roulade, tripe
7 to 8	Cooking	Potatoes, fritters, wafers
9	Frying, roasting, boiling water	Steaks, omelettes, fried dishes, water
P	Frying, roasting Boiling water	Scallops, steaks Boiling significant quantities of water

PART 6: MAINTENANCE AND CLEANING

Switch-off the appliance before cleaning.


Do not clean the hob if the glass is too hot because they are risk of burn.

- Remove small spots with a damp cloth using washing-up liquid diluted in a little water. Then rinse with cold water and dry the surface thoroughly.
- Highly corrosive or abrasive detergents and cleaning equipment likely to cause scratches must be avoided at all costs.
- Never use steam driven or high-pressure appliances.
- Do not use objects that might scratch the ceramic glass.
- Ensure that the pan is dry and clean and that there is no dust on your ceramic hob or on the pan. The use of rough saucepans will scratch the surface.
- Spillages of sugar, jam, jelly, etc. must be removed immediately to prevent a damaged surface.

PART 7: WHAT TO DO IN CASE OF A PROBLEM

When the symbol [E 4] appears:

- The table must be reconfigured. Please implement the following steps :
 - I) Important : before you start, make sure there is no more pot on the hob
 - II) Disconnect the appliance from the grid by removing the fuse or turning the circuit breaker off
 - III) Reconnect the table to the grid
 - IV) Procedure : take a pot with a ferromagnetic bottom and a minimum diameter of 16 cm
 - * start the procedure within 2 minutes after reconnecting the hob to the grid
 - * don't use the [O/I] touch
 - V) First step : cancel the existing configuration
 - 1) Press the touch n°2 and hold down
 - 2) The symbol [-] will appear on each display
 - 3) With your other hand, press successively and quickly (less than 2s) on each [-] display.
Begin from the front right side and turn contrary clockwise, as described on the picture (from a to d).
A double "beep" means an error occurred. If so, start again from item 1).
 - 4) Remove your fingers from the touch control, then push again on touch 1 during few seconds, until blinking [E] symbols appear.
 - 5) Wait until [E] symbols stop blinking.
 - 6) After few seconds, [E] are automatically transformed in [C]. The existing setup has been cancelled.
Note: For induction hobs with 3 cooking zones, as the right front zone doesn't exist in this case, begin the procedure with the right rear zone (b).
 - VI) Second step : new setup
 - 1) Take a ferromagnetic pot with a minimum diameter of 16 cm
 - 2) Select a cooking zone by pushing on the corresponding [C] display
 - 3) Place the pot on the area to be set
 - 4) Wait until the [C] display becomes a [-]. The selected cooking zone is now configured.
 - 5) Follow the same procedure for each cooking zone with a [C] display.
 - 6) All the cooking zones are configured once all the displays are turned off.
Please use the same pot for the whole procedure.
Never put several pots together on the zones during the setup-process.
- If [E 4] displaying remains, please call the customer care



The cooktop or the cooking zone doesn't start-up:

- The cooktop is badly connected on the electrical network.
- The protection fuse cut-off
- The locking function is activated
- The sensitive keys are covered of grease or water.
- An object is put on a key.

The control panel displays [U]:

- There is no pan on the cooking zone.
- The pan is not compatible with induction.
- The bottom diameter of the pan is too small.

The control panel displays [E]:

- Disconnect and replug the hob.
- Call the After-sales Service.

One or all cooking zones cut-off:

- The safety system functioned
- You forgot to cut-off the cooking zone for a long time.
- One or more sensitive keys are covered.
- The pan is empty and its bottom overheated.
- The hob also has an automatic reduction of power level and breaking Automatic overheating

Continuous ventilation after cutting-off the cooktop:

- This is not a failure, the fan continuous to protect the electronic device.
- The fan cooling stops automatically.

The control panel displays [L]:

- Refer to the chapter control panel locking.

The control panel displays [Π]:

- Refer to the chapter "Bridge".

The control panel displays [E] or [Er03]:

- An object or liquid covers the control keys. The symbol disappear as soon as the key is released or cleaned.

The control panel displays [E2] or [E H]:

- The hob is overheated, let it cool and then turn it on again.

The control panel displays [E3]:

- The pan is not adapted, change the pan.

The control panel displays [E6]:

- Defective network. Control the frequency and voltage of the electrical network.

The control panel displays [E8]:

- The air inlet of the ventilator is obstructed, release it.

The control panel displays [E C]:

- Configuration error. Set the table again, referring to the chapter "The [E 4] appears."


If one of the symbols above persists, call the SAV.

PART 8: INSTALLATION INSTRUCTIONS

The installation comes under the exclusive responsibility of specialists.
The installer is held to respect the legislation and the standards enforce in his home country.

How to stick the gasket:

The gasket supplied with the hob avoids all infiltration of liquids in the cabinet.
His installation has to be done carefully, in conformity of the following drawing.



Stick the gasket (2) two millimeters from the external edge of the glass, after removing the protection sheet (3).

Fitting - installing:

- The cut out sizes are:

Reference	Cut-size
PHD61FS	560 x 490 mm
PHD62FS	560 x 490 mm

- Ensure that there is a distance of 50 mm between the hob and the wall or sides.
- The hobs are classified as "Y" class for heat protection. Ideally the hob should be installed with plenty of space on either side. There may be a wall at the rear and tall units or a wall at one side. On the other side, however, no unit or divider must stand higher than the hob.
- The piece of furniture or the support in which the hob is to be fitted, as well as the edges of furniture, the laminate coatings and the glue used to fix them, must be able to resist temperatures of up to 100 °C.
- The mural rods of edge must be heat-resisting.
- Not to install the hob to the top of a not ventilated oven or a dishwasher.
- To guarantee under the bottom of the hob casing a space of 20 mm to ensure a good air circulation of the electronic device.
- If a drawer is placed under the work, avoid to put into this drawer flammable objects (for example: sprays) or not heat-resistant objects.
- Materials which are often used to make worktops expand on contact with water. To protect the cut out edge, apply a coat of varnish or special sealant. Particular care must be given to applying the adhesive joint supplied with the hob to prevent any leakage into the supporting furniture.
- This gasket guaranties a correct seal when used in conjunction with smooth work top surfaces.
- The safety gap between the hob and the cooker hood placed above must respect the indications of the hood manufacturer. In case of absence of instructions respect a distance minimum of 760 mm.
- The connection cord should be subjected, after building, with no mechanical constraint, such for example of the fact of the drawer.
- **WARNING:** Use only hob guards designed by the manufacturer of the cooking appliance or indicated by the manufacturer of the appliance in the instructions for use as suitable or hob guards incorporated in the appliance. The use of inappropriate guards can cause accidents.

PART 9: ELECTRICAL CONNECTION

- The installation of this appliance and the connection to the electrical network should be entrusted only to an electrician perfectly to the fact of the normative regulations and which respects them scrupulously.
- Protection against the parts under tension must be ensured after the building-in.
- The data of connection necessary are on the stickers place on the hob casing near the connection box.
- The connection to the main must be made using an earthed plug or via an omnipolar circuit breaking device with a contact opening of at least 3 mm.
- The electrical circuit must be separated from the network by adapted devices, for example: circuit breakers, fuses or contactors.
- If the appliance is not fitted with an accessible plug, disconnecting means must be incorporated in the fixed installation, in accordance with the installation regulations.
- The inlet hose must be positioned so that it does not touch any of the hot parts of the hob or even.

Caution!

This appliance has only to be connected to a network 230 V~ 50/60 Hz.

Connect always the earth wire.

Respect the connection diagram.

The connection box is located underneath at the back of the hob casing. To open the cover use a medium screwdriver. Place it in the slits and open the cover.

Mains	Connection	Cable diameter	Cable	Protection calibre
230V~ 50/60Hz	1 Phase + N	3 x 2,5 mm ²	H 05 VV - F H 05 RR - F	25 A *
400V~ 50/60Hz	2 Phases + N	4 x 1.5 mm ²	H 05 VV - F H 05 RR - F	16 A *

* Calculated with the simultaneous factor following the standard EN 60 335-2-6.

Connection of the hob

Setting up the configurations:

For the various kinds of connection, use the brass bridges which are in the box next the terminal

Monophase 230V~1P+N

Put a bridge between terminal 1 and 2.

Attach the earth to the terminal "earth", the neutral N to terminal 4, the Phase L to one of the terminals 1 or 2.

Biphase 400V~2P+N

Attach the earth to the terminal "earth", the neutral N to 4, the Phase L1 to the terminals 1 and the Phase L2 to the terminal 2.

Caution! Frequent loosening and screwing of the screws on the connection box risks damaging the efficiency of the tightness once screwed. It is therefore advisable to keep screwing and unscrewing to a minimum. Ensure that the cables are correctly inserted and tightly screwed down.

We cannot be held responsible for any incident resulting from incorrect connection or which could arise from the use of an appliance which has not been earthed or has been equipped with a faulty earth connection.

INSTRUCTIONS AND INFORMATION REGARDING THE DISPOSAL OF USED PACKAGING MATERIALS

Dispose of packaging material at a public waste disposal site.

DISPOSAL OF USED ELECTRICAL AND ELECTRONIC APPLIANCES



The meaning of the symbol on the product, its accessory or packaging indicates that this product shall not be treated as household waste. Please, dispose of this product at your applicable collection point for the recycling of electrical & electronic equipment waste. Alternatively in some states of the European Union or other European states you may return your products to your local retailer when buying an equivalent new product. The correct disposal of this product will help save valuable natural resources and help in preventing the potential negative impact on the environment and human health, which could be caused as a result of improper liquidation of waste. Please ask your local authorities or the nearest waste collection centre for further details. The improper disposal of this type of waste may fall subject to national regulations for fines.

For business entities in the European Union

If you wish to dispose of an electrical or electronic device, request the necessary information from your seller or supplier.

Disposal in other countries outside the European Union

If you wish to dispose of this product, request the necessary information about the correct disposal method from local government departments or from your seller.



This product meets all the basic EU regulation requirements that relate to it.

Changes to the text, design and technical specifications may occur without prior notice and we reserve the right to make these changes.

Manufacturer/Importer:
Fast ČR, a.s.
Praha 10, Černokostecká 2111
CZ-10000; CZECH REPUBLIC

PHILCO[®] 

**is a registered trademark used under license from
Electrolux Home Products., Inc.**