

surface of the unit. To clean, wipe it with mild non-abrasive detergent solution and clean soft cloth.

9. Never attempt to insert wires, pins or other such objects into the vents or opening of the unit.
10. Class 1 LED product

CAUTION

Danger of explosion if battery is incorrectly replaced
Replace only with the same or equivalent type

The projection clock must be set separately

TIME SETTING FOR PROJECTION UNIT

- To preset the Hours, press simultaneously the Hour button and the Time button. Keep them pressed until the hour digits to be preset are displayed.
- To preset the Minutes, press simultaneously the Minute button and the Time button. Keep them pressed until the minute digits to be preset are displayed.
- Focus setting : adjust the projection clock brightness / focus by turning the brightness / focus adjustment wheel until the projected time is clearly shown on the ceiling or wall.

NOTE : PROJECTS TIME IMAGE ON THE CEILING OR WALL OF A DARKENED ROOM. MAXIMUM PROJECTION DISTANCE IS 3-9 FEET.

Line in

The Line in jack can be used to playback alternate audio signal sources on the unit speakers.

This line in jack requires a 3.5mm audio cable for input signal.

Note : The 3.5mm audio cable is not included

EN Disposal of Used Electrical & Electronic Equipment



The meaning of the symbol on the product, its accessory or packaging indicates that this product shall not be treated as household waste. Please, dispose of this equipment at your

applicable collection point for the recycling of electrical & electronic equipments waste. In the European Union and Other European countries which there are separate collection systems for used electrical and electronic product. By ensuring the correct disposal of this product, you will help prevent potentially hazardous to the environment and to human health, which could otherwise be caused by unsuitable waste handling of this product. The recycling of materials will help conserve natural resources. Please do not therefore dispose of your old electrical and electronic equipment with your household waste. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.