

SENCOR[®]

SCH 630

Installation Guide & User Manual

1

EN

Instalační příručka & Návod k obsluze

5

CZ

Inštalacná príručka & Návod na obsluhu

9

SK

Telepítési kézikönyv & Használati útmutató

13

HU

Podręcznik instalacji & Instrukcja obsługi

17

PL

SCH 630 – USB AC /DC charger

1. General Description:

This model is a switching-mode charger for Mobile phone, Tablet PC and other suitable electronic product. This model operation at AC to DC, input 110-240V 50-60Hz, Output DC 5V/3.1Amp max , output power 15.5Watt max, with protection functions: Overload protection, Short Circuit Protection, power supply by mains supply.

2. Electric Characteristics:

No.	Item	Specification
1.	AC: Rated Input Voltage (47-63Hz)	AC110V OR AC230V
	AC: Vibration Input Voltage Range (50-60Hz)	AC110V-240V
2.	AC: Input Rated Current	0.6Amp
	AC: Input Power	110VA
3.	Output power (max)	15.5 W
	AC: Efficiency	>75%(TYP)
4.	USB port 5V ($\pm 5\%$)	USB port: 5V
5	Output Current: 2 USB port: 5V*2 @3.1Amp MAX	USB port: 5V@1Amp 5V@2.1Amp
6.	AC: Overload protection	YES
7.	AC: Short Circuit Protection	YES
8.	AC: Over voltage protection	YES
9.	Line Regulation	$\pm 2\%$
10.	Load Regulation	$\pm 5\%$

3. Normal Operating Temperature and Humidity:

3.1 Operating Temperature: 0°C to 40°C

3.2 Humidity: 20% to 80%

4. Storage Temperature and Humidity:

4.1 Storage Temperature: -10°C to 70°C

4.2 Humidity: 10% to 90%

5. Dimensions and weight:

H x W x D: 47 x 31 x 80 mm

Weight: 50g

6. Attention in using

The output characteristics of two USB are complete same, when only need charge one device, any USB port can output 3.1A max. The exact output will be adjusted automatically according to the demand from the device. When need charge two devices at the same time, the exact output of each USB will be distributed automatically according to the demand from the devices, but total output can't exceed 3.1A.

INSTRUCTIONS AND INFORMATION REGARDING THE DISPOSAL OF USED PACKAGING MATERIALS

Dispose of packaging material at a public waste disposal site.

DISPOSAL OF USED ELECTRICAL AND ELECTRONIC APPLIANCES



The meaning of the symbol on the product, its accessory or packaging indicates that this product shall not be treated as household waste. Please, dispose of this product at your applicable collection point for the recycling of electrical & electronic equipment waste. Alternatively in some states of the European Union or other European states you may return your products to your local retailer when buying an equivalent new product. The correct disposal of this product will help save valuable natural resources and help in preventing the potential negative impact on the environment and human health, which could be caused as a result of improper liquidation of waste. Please ask your local authorities or the nearest waste collection centre for further details. The improper disposal of this type of waste

may fall subject to national regulations for fines.

For business entities in the European Union

If you wish to dispose of an electrical or electronic device, request the necessary information from your seller or supplier.

Disposal in other countries outside the European Union

If you wish to dispose of this product, request the necessary information about the correct disposal method from local government departments or from your seller.



This product meets all the basic EU regulation requirements that relate to it.

Changes to the text, design and technical specifications may occur without prior notice and we reserve the right to make these changes.



EN Warranty conditions

Warranty card is not a part of the device packaging.

This product is warranted for the period of 24 months from the date of purchase to the end-user. Warranty is limited to the following conditions. Warranty is referred only to the customer goods using for common domestic use. The claim for service can be applied either at dealer's shop where the product was bought, or at below mentioned authorized service shops. The end-user is obligated to set up a claim immediately when the defects appeared but only till the end of warranty period. The end user is obligated to cooperate to certify the claiming defects. Only completed and clean (according to hygienic standards) product will be accepted. In case of eligible warranty claim the warranty period will be prolonged by the period from the date of claim application till the date of taking over the product by end-user, or the date the end-user is obligated to take it over. To obtain the service under this warranty, end-user is obligated to certify his claim with duly completed following documents: receipt, certificate of warranty, certificate of installation.

This warranty is void especially if apply as follows:

- Defects which were put on sale.
- Wear-out or damage caused by common use.
- The product was damaged by unprofessional or wrong installation, used in contrary to the applicable instruction manual, used in contrary to legal enactment and common process of use or used for another purpose which has been designed for.
- The product was damaged by uncared-for or insufficient maintenance.
- The product was damaged by dirt, accident of force majeure (natural disaster, fire, and flood).
- Defects on functionality caused by low duality of signal, electromagnetic field interference etc.
- The product was mechanically damaged (e.g. broken button, fall).
- Damage caused by use of unsuitable media, fillings, expendable supplies (batteries) or by unsuitable working conditions (e.g. high temperatures, high humidity, quakes).
- Repair, modification or other failure action to the product by unauthorized person.
- End-user did not prove enough his right to claim (time and place of purchase).
- Data on presented documents differs from data on products.
- Cases when the claiming product cannot be identified according to the presented documents (e.g. the serial number or the warranty seal has been damaged).

Authorized service centers

Visit www.sencor.eu for detailed information about authorized service centers.

