

# SENCOR®

## SDC 7900 Qi



User's manual

Návod k obsluze

Návod na obsluhu

Használati útmutató

Instrukcja obsługi

NIGHT LIGHT ALARM CLOCK  
WITH A WIRELESS CHARGER

BUDÍK S NOČNÍM SVĚTLEM  
A BEZDRÁTOVOU NABÍJEČKOU

BUDÍK S NOČNÝM SVETLOM  
A BEZDRÔTOVOU NABÍJAČKOU

ÉBRESZTŐÓRA ÉJSZAKAI FÉNNYEL  
ÉS VEZETÉK NÉLKÜLI TÖLTŐVEL

BUDZIK Z NOCNYM ŚWIATŁEM  
I ŁADOWARKĄ BEZPRZEWODOWĄ

EN CZ SK HU PL

## FUNCTION BUTTONS



- 1 Child lock setting / atmospheric light button
- 2 Alarm / clock button
- 3 + button
- 4 - button
- 5 Hour
- 6 Time indicator
- 7 Minute
- 8 Power supply connection by a C Type connector
- 9 USB-A output (5V, 1A)
- 10 Charging area
- 11 Lock indicator
- 12 PM indicator (afternoon)
- 13 Alarm 1 indicator
- 14 Alarm 2 indicator

## FUNCTION

### A. Power supply connection

1. Connect the USB-A cable end to the power adapter, then connect the type C cable end to the alarm clock.
2. All indicators will light up and the alarm clock will switch to the standby mode.

### B. Wireless charging

1. Place your phone supporting the wireless charging feature on the top of the alarm clock. If your phone supports this function, phone battery charging process will start. Please check the exact induction coil location with your phone manufacturer to reach the highest possible charging process efficiency.

**Tip:** The alarm clock should be powered via the supplied charging adapter supporting QC2.0/QC3.0 so that the wireless charging can function correctly.

**Caution:** Both devices are being heated during the wireless charging process. The charging may be interrupted by an elevated temperature. Remove the phone from the alarm clock charging area before resuming the charging. You can put the phone back once cooled down.

#### 2. Charging status indicator

- **blue light:** wireless charging of the placed device is in progress
- **blue fast flashing indication:** a phone not supporting the wireless charging feature is placed on the alarm clock charging area
- **no indication:** no charging is in progress (the charging has finished or no device has been placed)

## C. USB

The USB-A (5V, 1A) port is designed to charge devices not supporting the wireless charging.

**Caution:** The USB port does not support the QC 2.0/QC 3.0 mode transfer.

## D. Alarm/clock function

### 1. Setting the time format:

To toggle between 12-hour or 24-hour time format, tap the Alarm/Clock button. If the 12-hour time format is set, the PM indicator will be shown.

### 2. Setting the time:

- 1) Tap the Alarm/Clock button once to open the minute setting and adjust the value by +/- button.
- 2) When the minutes are set, tap the Alarm/Clock button once to open the hour setting and adjust the value by +/- button.
- 3) To finish the time setting, tap the Alarm/Clock button the third time.

### 3. Setting the alarm:

- 1a) To enable or disable alarm No.1, hold down the "+" button for 3 seconds.
- 1b) To enable or disable alarm No.2, hold down the "-" button for 3 seconds.
- 1c) The alarm indicator will light once the alarm is enabled.
- 2a) Hold down the Alarm/Clock button once to open the alarm No.1 minute setting and adjust the value by +/- button.
- 2b) When alarm No.1 is set, tap the Alarm/Clock button to open alarm No.2 setting and adjust the value by +/- button.
- 3) If no action is done, the alarm will sound for 3 minutes and then turn off automatically.
- 4) To switch the alarm clock into the sleep mode, touch any button while the alarm sound is output. The alarm will sound 2 more times after 5 minutes. In the sleep mode, the indicator flashes and the Alarm/Clock button is disabled. To adjust time, long press the "+" to stop alarm No.1 or long press the "-" button to stop alarm No.2. All buttons will function in a normal way.

### 4. Display brightness:

The brightness of the time display can be adjusted with the +/- buttons to 5 modes. To turn off the display completely, press the - button repeatedly until the display goes off. Use the + button to switch the display back on.

**Caution:** Individual brightness levels and the wireless charging function of the mobile phone can be accompanied by a soft acoustic tone.

### 5. Night light setting:

The night light can be set in 10 colour modes: white, alternating RGB shades, selected RGB shade colour: red, orange, yellow, green, blue, dark blue, pink. Hold down the atmospheric light button for 2 seconds to immediately turn off the night light.

6. **Child lock setting:**

To unlock/lock the child lock, double tap the child lock touch button in the touch button area. When the child lock is unlocked, the lock indicator on the display screen will disappear, the clock indicator will stop flashing and all touch buttons in the touch button area will be enabled.

**Caution:** The child lock is not indicated when the display is off. Do not use the button lock in this mode.

7. **Battery function:**

- 1) A replaceable battery is only designed for the time function backup.
- 2) All functions are disabled when the power is disconnected. The functions will be enabled once the power is connected.

## **E Note**

1. **Caution:** In order to ensure proper function of alarm clock, wireless charging, night light and USB output, the power must be connected via a QC2.0 or QC3.0 adapter. When connected via other 5V adapter, the QI mode is not supported (the wireless charging speed will decrease).
2. Do not expose the alarm clock to pressure and shocks.
3. Do not disassemble and/or expose the alarm clock to high temperatures and avoid contact with liquids.
4. Do not place the alarm clock in the close proximity to magnetic cards (ID cards, bank cards etc.) with magnetic strips or chips to avoid damage to the card.
5. Please keep a minimum distance of 20cm between this wireless charger and medical implants (pacemakers, cochlear implants etc.) to prevent damage to the medical devices.
6. Make sure to keep a safe distance between children and the alarm clock.
7. Before cleaning the alarm clock, make sure to disconnect the power source. For cleaning, always use a slightly moistened soft cloth. Do not use detergents or abrasive cleaning agents.
8. Operating temperature: 0-45°C.
9. Operating humidity: 20-85% (40°C)
  - The pictures in this manual are for illustrative purposes only. Your product may have a different appearance.
  - Package contents: alarm clock with charging adapter, charging cable, user's manual.
  - The QC2.0/ QC3.0 power adapter is part of the supplied accessories.

## TECHNICAL SPECIFICATIONS

<b>Input:</b>	9 V / 2 A / 12 V / 1,5 A / 5 V / 3 A
<b>Power output:</b>	10 W (max.)
<b>Charging power output:</b>	15W
<b>Backup battery:</b>	1 × CR-2032 3 V
<b>USB output:</b>	5 V – 1 A (max.)
<b>Power consumption:</b>	18 W (max.)
<b>Power output of the wireless charger:</b>	10 W (max.)
<b>Charging efficiency:</b>	73%
<b>Charging distance:</b>	≤ 8mm
<b>Frequency:</b>	110-205kHz
<b>Dimensions:</b>	141 × 74 × 117 mm (W × H × D)

## CHARGING ADAPTER

<b>Manufacturer's name or trademark, trade registration number and address:</b>	Shenzhen JiaYu Electronics Co. Ltd, 3/F NO.20 Fengye Five Rd, Fenghuang, vesnice Fuyong Street Bao'an District, Shenzhen, P.R. Čína
<b>Identification mark of the model:</b>	5751
<b>Input voltage:</b>	AC100 – 240V
<b>Input frequency:</b>	50/60 Hz
<b>Output voltage:</b>	DC5.0V / DC9.0V / DC12.0V
<b>Output current:</b>	3.0A (5V) / 2.0A (9V) / 1.5A (12V)
<b>Power output:</b>	18.0W
<b>Average efficiency in active mode:</b>	≥80.00%
<b>Efficiency at low load (10%):</b>	76.00%
<b>No-load power consumption:</b>	≤0.01 W

## SUPPORTED DEVICES

Qi compliant products.

## INSTRUCTIONS AND INFORMATION ABOUT THE DISPOSAL OF DISCARDED PACKAGE

Return the packaging to a collection centre for disposal.

## DISPOSAL OF DISCARDED ELECTRICAL AND ELECTRONIC EQUIPMENT



This symbol placed on the product, accessories or package notifies that the product must not be treated as household waste. Please dispose of this product in a collection centre designed for recycling electric and electronic equipment. In some EU or European countries, you can return your products to your local dealer when buying a new equivalent product. Correct disposal of this product helps save valuable natural resources and prevents possible adverse impacts on the environment and human health that might be caused by improper waste disposal. For further information, please contact your local authorities or the nearest waste disposal collection centre. Wrong disposal of this type of waste may be subject to a legal penalty.

### For EU companies

If you need to dispose of an electric or electronic device, ask your dealer your supplier for necessary information.

### Disposal in countries outside the European Union

To dispose of this product, please ask your local authorities or dealer for the necessary information on correct disposal.



This product complies with EU requirements.

FAST ČR, a. s. hereby declares that the radio device type SDC 7900 Qi complies with Directive 2014/53/EU. The full text of the EU Declaration of Conformity is available at the following web address: [www.sencor.cz](http://www.sencor.cz)

Changes in the text, design and technical specifications may be made without prior notice and we reserve the right to make such changes.

The original version is in Czech.

Manufacturer's address: FAST ČR, a. s., U Sanitasu 1621, Říčany CZ-251 01

# SENCOR®

## EN Warranty conditions

**Warranty card is not a part of the device packaging.**

This product is warranted for the period of 24 months from the date of purchase to the end-user. Warranty is limited to the following conditions. Warranty is referred only to the customer goods using for common domestic use. The claim for service can be applied either at dealer's shop where the product was bought, or at below mentioned authorized service shops. The end-user is obligated to set up a claim immediately when the defects appeared but only till the end of warranty period. The end user is obligated to cooperate to certify the claiming defects. Only completed and clean (according to hygienic standards) product will be accepted. In case of eligible warranty claim the warranty period will be prolonged by the period from the date of claim application till the date of taking over the product by end-user, or the date the end-user is obligated to take it over. To obtain the service under this warranty, end-user is obligated to certify his claim with duly completed following documents: receipt, certificate of warranty, certificate of installation.

### **This warranty is void especially if apply as follows:**

- Defects which were put on sale.
- Wear-out or damage caused by common use.
- The product was damaged by unprofessional or wrong installation, used in contrary to the applicable instruction manual, used in contrary to legal enactment and common process of use or used for another purpose which has been designed for.
- The product was damaged by uncared-for or insufficient maintenance.
- The product was damaged by dirt, accident of force majeure (natural disaster, fire, and flood).
- Defects on functionality caused by low duality of signal, electromagnetic field interference etc.
- The product was mechanically damaged (e.g. broken button, fall).
- Damage caused by use of unsuitable media, fillings, expendable supplies (batteries) or by unsuitable working conditions (e.g. high temperatures, high humidity, quakes).
- Repair, modification or other failure action to the product by unauthorized person.
- End-user did not prove enough his right to claim (time and place of purchase).
- Data on presented documents differs from data on products.
- Cases when the claiming product cannot be indentified according to the presented documents (e.g. the serial number or the warranty seal has been damaged).

### **Authorized service centers**

Visit [www.sencor.com](http://www.sencor.com) for detailed information about authorized service centers.