




FZG 9001-E

---

1



# Electric Charcoal Starter

## **OPERATING INSTRUCTIONS**

### CONTENTS

FIGURES .....	3
1. GENERAL SAFETY REGULATIONS .....	6
Important safety instructions	
Packaging	
User manual	
2. MACHINE DESCRIPTION .....	7
3. IMPORTANT SAFETY INSTRUCTIONS .....	7
4. OPERATION .....	8
5. TECHNICAL SPECIFICATIONS .....	9
6. DECLARATION OF CONFORMITY .....	10
7. DISPOSAL .....	11
WARRANTY CERTIFICATE, CONDITION OF GUARANTEE .....	96 - 101

# 1. GENERAL SAFETY INSTRUCTIONS

## Important safety warnings

- ✿ Unpack the product carefully and be sure not to throw away any part of the package before having found all components of the product.
- ✿ Keep the product in a dry place out of reach of children.
- ✿ Read all cautions and instructions. The failure to adhere to warning cautions and instructions may result in an accident, fire and/or a serious injury.

## Packaging

The product is placed in a package preventing damage during transport. This package is a raw material therefore it can be handed-over for recycling.

## Instructions for use

Before beginning to work with the machine, read the following safety rules and instructions for use. Familiarize with operating elements and the proper use of the device. Keep the manual in a safe place for future reference. We recommend keeping the original package including the inner packaging materials, cash voucher and guarantee card for a period of warranty at minimum. For a case of transportation, pack the machine into the original box from the manufacturer, thus ensuring a maximum protection of the product during a possible transport (e.g. moving or sending into a service station).

 **Note:** If you hand the machine over to next persons, hand it over together with the manual. Adherence to the attached instructions for use is a precondition for the proper use of the machine. The operation manual includes also instructions for operation, maintenance and repairs.

**The manufacturer does not take any responsibility for accidents or damages resulting from the failure to adhere to this manual.**

## 2. MACHINE DESCRIPTION

### Machine Description (see Fig. 1)

- 1 - heating element
- 2 - stand
- 3 - handle
- 4 - cable
- 5 - Limit (charcoal)

## 3. IMPORTANT SAFETY INSTRUCTIONS

**⚠ WARNING!** Please note the following safety notes to avoid malfunctions, damages or physical injuries:

- ✿ Make sure, that the nominal voltage on the type label corresponds to the mains voltage of your domestic electrical installation.
- ✿ Persons with limited physical, sensorial or mental abilities are not allowed to use the unit, unless they are supervised for their safety by a qualified person or are briefed by the responsible person how to use the unit.
- ✿ Store the packaging material out of reach of children. There is a risk of suffocation.
- ✿ Keep children and animals away from the hot barbeque lighter and the barbeque! There is a risk of burns! The barbeque lighter is not a toy.
- ✿ Never leave the activated barbeque lighter and the hot barbeque unattended.
- ✿ Use the unit only outdoors.
- ✿ The heating element of the barbeque lighter is very hot during operation and for some minutes after use. Only grasp the unit by the handle!
- ✿ Keep the barbeque lighter away from flammable materials and liquids.
- ✿ Do not use any additional (liquid) barbeque starters.
- ✿ Unplug the barbeque lighter after approx. 10 – 15 minutes when the charcoal briquettes are smouldering well.
- ✿ Do not clean the barbeque lighter in the dishwasher.
- ✿ Do not misuse the unit to boil water. Never immerse the unit in water or other liquids! Ensure that the unit, the power cord or plug do not fall in water or are at risk of getting wet. Do not use the unit in rain or snow or when the unit has become wet.
- ✿ If the unit has fallen in water, immediately disconnect the power supply.
- ✿ Ensure that the power cord is not squeezed or kinked and that it does not come into contact with hot surfaces.
- ✿ Ensure that the power cord can not become a tripping hazard.

- ✿ For using the unit, we recommend the use of an RCD with a residual current < 30 mA. In Switzerland the utilisation of an RCD is obligatory. Ask your installation technician for advice in this matter.
- ✿ First allow the barbecue lighter to cool down completely before cleaning, storing or when not in use.
- ✿ Allow the charcoal to cool down completely before you dispose of the coal/the ashes.
- ✿ Clean the barbecue lighter after each use.
- ✿ Never pull the power cord, but always use the power plug to unplug the unit. The barbecue lighter is only switched off when it is unplugged.
- ✿ If the device, the power cord or the plug exhibit visible damages, the device may not be used any further. Have it repaired by a qualified workshop.
- ✿ Do not disassemble the device and do not try to repair it yourself. The device does not contain any parts serviceable by you. In case of questions or problems turn to our customer service.
- ✿ Always also pay attention to the safety notes provided by the manufacturer of the barbecue being used.

## 4. OPERATION

### Intended Use

- ✿ This product is design for starting barbecue charcoal and briquettes. The product is designed for private, not for commercial use. Only use the product with charcoal barbecues and not with gas or electric barbecues. Use it only as described in the instructions.
- ✿ The intended use also includes an operation following the operating instructions.
- ✿ Any use beyond these parameters (different media, applying force) or any changes (reconstruction, no original accessory) can lead to serious risks and is regarded as use that is contrary to the intended purpose.

### Using

**⚠ WARNING!** Children are not allowed to operate with the barbecue lighter

**⚠ WARNING!** Make sure that the barbecue lighter is in proper position.

- ✿ Put the barbecue on a stable, horizontal and heat resistant surface. Cover the bottom of the barbecue with a layer of charcoal or briquettes.
- ✿ Place the heating element (1) of the barbecue lighter on this layer. Ensure that the handle (3) is situated on the outside of the barbecue.
- ✿ Now stack several pieces of charcoal or briquettes in the shape of a pyramid on the heating element of the barbecue lighter.
- ✿ Double check the proper position of the barbecue lighter and the power cord.
- ✿ Connect the barbecue lighter to an earthed contact socket earthed according to regulations (230 V~ 50 Hz).

- ✿ Depending on the quality and quantity of the charcoal being used, the barbecue lighter should smoulder the coal for approx. 10 – 15 minutes. Then unplug the device. Grasp the handle and carefully remove it from the barbecue.
- ⚠ **WARNING!** Before you take the barbecue lighter out of burning charcoal or briquettes first unplug it out of the power.
- ⚠ **WARNING!** Caution hot! Grasp the barbecue lighter only by the handle (3)!
- ⚠ **WARNING!** If the electric barbecue lighter is not in use put it in its stand.
- ✿ Put the barbecue lighter as pictured on the overview page III, on the support (2) and allow cooling down completely. Place the support on an appropriately big, horizontal and heat resistant surface. Ensure that nobody can get burnt and that no objects can be ignited by the hot barbecue lighter.
- ✿ Distribute the smouldering coals on the barbecue.

### Cleaning and Storing

- ✿ Allow the barbecue lighter to cool down completely before cleaning or storing!
- ✿ Do not use any scouring or abrasive cleaners for cleaning the barbecue lighter.
- ✿ Only clean the device with a damp cloth or with a brush.
- ✿ Store the barbecue lighter on a dry place that is protected from dust, dirt and extreme temperatures.
- ✿ Store the barbecue lighter out of reach of children.

## 5. TECHNICAL SPECIFICATIONS

Rated Voltage: .....	230 V 50 Hz
Rated Power: .....	800 W
Power Cord Length: .....	1 m
Heating Coil: .....	1.50 m
Protection Class: .....	I
Dimensions BBQ Lighter: .....	50 x 19.2 cm
Weight BBQ Lighter: Approx. ....	0.45 kg
Dimensions Support: .....	19 x 15 x 6.3 cm

User Manual – Language version only.

# 6. DECLARATION OF CONFORMITY

**Tipo / Modelo:**

FZG 9001-E ..... 230V/50Hz/800W

**El producto cumple con los requisitos esenciales de las siguientes directivas europeas:**

- ☼ Directiva 2006/95/CE, sobre equipos eléctricos destinados a utilizarse con determinados límites de tensión (Baja Tensión)
- ☼ Directiva 2004/108/CE relativa a la compatibilidad electromagnética (EMC)
- ☼ Directiva 2011/65/UE sobre la restricción del uso de ciertas sustancias peligrosas en equipos eléctricos y electrónicos (RoHS)

Incluidos los suplementos.

Certificación CE:.....14

La empresa FAST ČR, a.s. está autorizada a obrar en nombre del fabricante.

**Fabricante:**

FAST ČR, a.s.

Černokostelecká 2111, 100 00 Praha 10

NIF: CZ26726548

En Praga, al 23 de diciembre de 2013.

Nombre: Zdeněk Pech

Presidente de la Junta Directiva



Firma y estampilla:

## 7. DISPOSAL

### **INSTRUCTIONS AND INFORMATION ON DISPOSAL OF USED PACKAGING.**

Put any used package material to the place determined by the municipality for waste disposal.

### **DISPOSAL OF USED ELECTRIC AND ELECTRONIC EQUIPMENT**



This symbol on products or accompanying documents means that used electric or electronic products must not be put to ordinary municipal waste. Hand over such products to determined collection points for proper disposal, restoration and recycling. Alternatively, in some countries of the European Union or other European countries you can return your products to your local dealer when you buy an equivalent new product. By dutiful disposal of this product you can preserve precious natural resources and you help prevent any potential adverse effects on the environment and human health which could be the results of wrong waste disposal. Ask your local authority or the nearest collection point for additional details. In case of improper disposal of this waste kind penalties can be imposed in accordance with national regulations.

#### **For companies in the European Union countries**

Should you want to dispose of electric and electronic devices, ask your dealer or vendor for necessary information.

#### **Disposal in other countries outside the European Union**

Should you want to dispose of this product, ask your local authorities or your dealer for necessary information about disposal method.



This product fulfils all basic requirements of the EU directives that apply to it.

Text, design and technical specifications can change without prior notice and we reserve the right for their change.

