

lamart

by Pierre Lamart

STRAW

EN Dear customer,

you are now holding: sports bottle with straw. Reclosable nozzle sealing mechanism with silicone seal prevents the bottle from opening. Very light, comfortable for outdoor use. Easy care and cleaning.

Operating instructions:

- 1) Wash out the bottle before every use with hot or cold water depending on the beverage that you will pour into the bottle.
- 2) Never fill the bottle higher than the bottom edge of the pouring part of the bottle, i.e. be at least 1–1.5 cm under the rim of the bottle. Never pour boiling beverages into the bottle.
- 3) Always pour out unconsumed beverages to prevent deposits from forming inside the bottle and potential bacterial growth. Always be careful when handling the bottle.
- 4) Before first use, always wash the product and wipe dry.
- 5) To remove light stains, allow the bottle to soak and then wipe it dry with a soft wiping cloth.
- 6) Bottles are very easy to maintain and clean; when cleaning by hand use only soft wipes and sponges. Do not use aggressive chemical products.
- 7) To achieve a long lifetime of the product, handle the bottle with care – avoid strong impacts and shocks. Always store opened.
- 8) **ATTENTION:** carbonated and sparkling beverages, ice cubes or dairy products do not belong in the bottle. The bottle is not to be used for baby food.
- 9) Designed for domestic use
- 10) The 3-year warranty does not cover: damage caused by the product falling or being impacted, technical modifications of the bottle.

Safety notice:

High temperatures may damage the bottle or the cap. The use of sharp metal utensils (e.g. knives, forks) may damage (scratch) the surface. The use of coarse or aggressive cleaning agents can damage the surface (e.g. caustic pipe cleaning agents). Negligent handling (e.g. of the lid) may lead to surface damage (chipping). **These „footprints“ do not have the slightest effect on the quality of the prepared food or beverages nor on the lifetime of the bottle, they only affect its aesthetic appearance.** Through the effect of high temperature of the heat source, the surface may be damaged.

Ecology:

Depending on the size of the product, all products have marks printed on them denoting the material used for the production of the packaging, component and accessories, as well as their recycling. Correct disposal of this product helps save valuable natural resources and prevents damage to the environment caused by improper waste disposal. Ask your local authorities or collection facility for more details. In accordance with national regulations penalties may be imposed for the incorrect disposal of this type of waste. **Keep plastic bags out of the reach of children, danger of suffocation.**

The purchaser was informed about the function and handling of the product.