

lamart

by Pierre Lamart

HEAT



EN Dear customer,

you are now holding: a glass tea kettle suitable for all types of teas, tea beverages and cold drinks (100°C). The kettle's handle is made from durable plastic. The kettle contains a stainless steel strainer for loose tea, fruit pieces or tea herbs. The kettle is equipped with a plastic lid for easy access for cleaning and filling up. The tea kettle is suitable for cooking plates.

Instructions for use:

1. This product is made from very high quality, yet fragile glass – always be careful not to crack it when cleaning, handling or using the product.
 2. Before first using the kettle, rinse and thoroughly wipe it out.
 3. When using the kettle, never fill higher than the bottom edge of the pouring part of the kettle, i.e. spout.
 4. In the event that a crack appears on the kettle, immediately stop using it; there is a risk of cracking.
 5. Never leave a hot beverage in the kettle without supervision and within reach of children. Allow the kettle to cool down before cleaning it. Always pour out unconsumed water or tea from the kettle, you will avoid the formation of deposits inside the kettle. Always be careful when handling hot water (the kettle), and use a kitchen glove if necessary.
 6. To remove light stains caused by tea or acidic beverages, leave the it to soak in hot water with detergent and then wipe dry using a soft cloth. In the event of heavier stains, heat up some white vinegar and then wash as usual. These stains have no effect on the properties of the product.
 7. A glass kettle is very easy to maintain and clean; when cleaning by hand, use only soft wipes and sponges that will not scratch the surface. Do not use aggressive chemical products. Washing in a dishwasher is not possible.
 8. To achieve a long lifetime of the product, handle the kettle with care.
 9. Do no use on any source of naked flame.
 10. Always keep the filter clean – remove deposits and remains of used ingredients.
 11. Designed for domestic use
- 

Safety notice:

High or low temperatures may damage the kettle or the lid through cracking. The use of sharp metal utensils (e.g. knives, forks) may damage (scratch) the surface. The use of coarse or aggressive cleaning agents can damage the surface (e.g. caustic pipe cleaning agents). Negligent handling (e.g. of the lid) may lead to surface damage (chipping). **These “footprints” do not have the slightest effect on the quality of the prepared beverage nor on the lifetime of the kettle, they only affect its aesthetic appearance.**

Ecology:

Depending on the size of the product, all products have marks printed on them denoting the material used for the production of the packaging, components and accessories, as well as their recycling. Correct disposal of this product helps save valuable natural resources and prevents damage to the environment caused by improper waste disposal. Ask your local authorities or collection facility for more details. In accordance with national regulations penalties may be imposed for the incorrect disposal of this type of waste. **Keep plastic bags out of the reach of children, danger of suffocation.**

The purchaser was informed about the function and handling of the product.





Výrobce/Manufacturer: FAST ČR, a.s.; Černokostelecká 2111, 100 00 Praha 10, Czech Republic

www.lamart.cz