



EN ■ Variable Temperature Electric Kettle

READ CAREFULLY AND STORE FOR FUTURE USE.

- This appliance may be used by children 8 years of age and older and by persons with physical or mental impairments or by inexperienced persons, if they are properly supervised or have been informed about how to use the product in a safe manner and understand the potential dangers. Cleaning and user maintenance must not be performed by children unless they are older than 8 years of age and under supervision. Keep this appliance and the power cord out of reach of children that are younger than 8 years of age. Children must not play with the appliance.
- The kettle is designed for domestic use and similar places such as:
 - staff kitchens in stores, offices and other workplaces;
 - hotel or motel rooms and other living areas;
 - agricultural farms;
 - bed and breakfast establishments.
- Do not place the kettle on window sills, kitchen sink drainboards or unstable surfaces. Always place it on a stable, even and dry surface.
- Do not place the kettle on equipment or devices that are sources of heat.
- Before connecting the kettle to a power socket check that the nominal voltage matches the electrical voltage in the socket. Connect the kettle only to a properly grounded socket.
- Only use the kettle with the base that was supplied with it.
- Never use the kettle in the near vicinity of a bath, shower or swimming pool.
- Do not wash the kettle or its base under running water and do not submerge it or its base in water or another liquid.
- Use the kettle exclusively for boiling drinking water. Do not use it to heat other liquids or foodstuffs.
- Do not fill the kettle when it is located on the base. Take the kettle off the base before filling it. When filling, make sure that the water level covers at least the minimum mark and also that it does not go over the maximum mark. If the kettle is overfilled, then boiling water could splash out.
- Take care not to spill water on to the connector when placing the kettle on to the base or when taking it off the base.
- Check that the lid is securely closed before starting the kettle. Do not open the lid or handle it in any way while the water is boiling.




Attention:

Incorrect use may lead to injuries.


- Do not turn on the kettle when it is empty. Incorrect use may negatively affect its lifetime. For the event that it is accidentally started without water, the kettle is equipped with a safety mechanism that protects it against damage.

- The surface of the heating element and kettle body is heated during use and remains hot after use due to residual heat. Do not touch the hot surface. Use the handle for lifting and carrying the kettle.
- Be especially careful when pouring water out of the kettle to avoid scalding by the boiling water or steam.
- Do not pour icy cold water into the hot kettle.
- Always disconnect the kettle from the power socket when not using it, when leaving it without supervision, before moving or cleaning it.
- Keep the kettle clean. Clean it according to the instructions in chapter Cleaning and maintenance.
- Disconnect the kettle from the power socket by gently pulling the plug of the power cord, and not the power cord itself. Otherwise, this could damage the power cord or the socket.
- If the power cord is damaged, it must be replaced by an authorised service centre or by another similarly qualified person, this will prevent the creation of a dangerous situation. It is forbidden to use the appliance if it has a damaged power cord.
- To avoid the danger of injury by electrical shock, do not repair the kettle yourself or make any adjustments to it. Have all repairs performed at an authorised service centre. By tampering with the appliance, you risk voiding your legal rights arising from unsatisfactory performance or quality warranty.

A



B



Variable Temperature EN Electric Kettle

User's manual

- Prior to using this appliance, please read the user's manual thoroughly, even in cases, when one has already familiarised themselves with previous use of similar types of appliances. Only use the appliance in the manner described in this user's manual. Keep this user's manual in a safe place where it can be easily retrieved for future reference.
- We recommend saving the original cardboard box, packaging material, purchase receipt and responsibility statement of the vendor or warranty card for at least the duration of the legal liability for unsatisfactory performance or quality. In the event of transportation, we recommend that you pack the appliance in the original box from the manufacturer.

DESCRIPTION OF THE KETTLE

- A1** Open lid button
- A2** Lid
- A3** Spout
- A4** Water level mark
- A5** Base with a central connector
- A6** Control panel
- A7** Handle
- A8** Internal LED light

DESCRIPTION OF THE CONTROL PANEL

- B1** Temperature setting LED indicators
- B2** Set temperature touch button – 60, 70, 80 and 90 °C.
- B3** On/Off touch button

BEFORE FIRST USE OF THE KETTLE

1. Remove all wrapping material from the kettle and its base **A5**.
2. Fill the kettle with clean water up to the maximum water mark. Boil the water and empty the contents of the kettle. Repeat this process 2 to 3 times.



Note:

To boil water in the kettle proceed according to the instructions in chapter Using the kettle.

3. Now the kettle is ready for operation.

USING THE KETTLE

1. Set the desired length of the power cord. Push the power cord into the groove in the base **A5**. Place the base **A5** on a stable, even and clean surface.
2. Fill the kettle with the required amount of water. To open the lid **A2**, press button **A1**. The water level must reach at least the minimum mark (0.5l) but must not exceed the maximum mark (1.8l). After filling it, close the lid **A2** and make sure that it is secured in the closed position.



Attention:

Do not fill the kettle when it is placed on the base **A5**. When overfilling, there is a risk of boiling water splashing out.

3. Place the kettle on the base **A5** and insert the power cord plug into a power socket. When the power cord is connected to a power socket, a short beep is made, the control panel **A6** and the LED light **A8** is lit for a brief moment. The kettle will then switch to standby mode and is ready for use. In standby mode, the red indicator on button **B3** will flash.

4. Operating mode settings:

4.1 Boil water mode

- To start the water boiling process, press button **B3**. A sound signal confirms that the button was pressed. The indicator on button **B3** will be lit, the kettle will start heating water to 100 °C. During operation, the LED light **A8** is lit red. When the water comes to a boil, the kettle will turn off automatically, LED light **A8** will turn off and the indicator on button **B3** will start flashing.



Note:

The water boiling process can be stopped at any time by again pressing button **B3** or lifting the kettle off the base **A5**.

4.2 Boil water then keep warm mode

- Press button **B3** and hold it down for approx. 2 seconds. A sound signal will be made and the indicator on buttons **B2** and **B3** will be lit. The kettle will start heating water to 100 °C. During operation, the LED light **A8** will flash red.
- Once the water has come to a boil, a sound signal will be made and the kettle will automatically switch to the keep warm mode. The LED light **A8** flashes constantly and the indicators on buttons **B2** and **B3** remain lit. In this mode, the heating element automatically switches on and off to maintain temperature. The time of keep warm mode is preset to 120 minutes. After this time has elapsed, the kettle will turn off automatically. If you wish to end this mode sooner, press button **B3** or lift the kettle off the base **A5**.

4.3 Heat water to set temperature mode

- Press button **B3** and then use button **B2** to select the desired temperature of 60, 70, 80 or 90 °C. The temperature setting changes each time the button is pressed, and is indicated by the respective indicator **B1** being lit. Each press of the button is accompanied by a short beep. The kettle will heat the water to the selected temperature and during operation the LED light **A8** will be lit:
 - green when the temperature is set to 60 °C.
 - blue when the temperature is set to 70 °C.
 - yellow when the temperature is set to 80 °C.
 - violet when temperature is set to 90 °C.
- When the set temperature is reached, the kettle will turn off automatically. The respective indicator **B1** will be flashing on the control panel **A6** and the control buttons are not lit. After 2 minutes the kettle will switch to the standby mode.



Note:

The temperature setting can be changed while the appliance is running.

If you set a lower temperature than the current temperature of the water inside the kettle, a sound will be made and the kettle will turn off automatically.

4.4 Heat water to set temperature then keep warm mode

- Press button **B3** and hold it down for approx. 2 seconds. A sound signal is made. Use button **B2** to select the desired temperature of 60, 70, 80 or 90 °C. The temperature setting changes each time the button is pressed, and is indicated by the respective indicator **B1** being lit. Indicator lights **B2** and **B3** will be lit. The kettle will heat the water to the selected temperature and during operation the LED light **A8** will be flashing:
 - green when the temperature is set to 60 °C.
 - blue when the temperature is set to 70 °C.
 - yellow when the temperature is set to 80 °C.
 - violet when temperature is set to 90 °C.
- When the set temperature is reached, a sound signal will be made and the kettle will switch to the keep warm mode. The LED light **A8** flashes constantly and the indicators on buttons **B2** and **B3** and the respective indicator **B1** remain lit. In this mode, the heating element automatically switches on and off to maintain the set temperature. The time of keep warm mode is preset to 120 minutes. After this time has elapsed, the kettle will turn off automatically. If you wish to end this mode sooner, press button **B3** or lift the kettle off the base **A5**.



Attention:

If the kettle is not located on the base **A5**, the control buttons **B2** and **B3** will not react to being pressed.

Lifting the kettle off the base will cancel all previous settings. When the kettle is put back on the base **A5**, the kettle will switch to standby mode and is again ready for use.

This kettle is not calibrated for scientific or laboratory purposes. The actual water temperature may differ by ± 5 °C from the set water temperature.



Attention:

Do not turn on the kettle when it is empty. Incorrect use may negatively affect its lifetime. If you accidentally turn on the kettle without water, it will turn itself off within a few moments. Wait until the heating element cools down. This is indicated by a sound, the control panel **A6** and the LED light **A8** being lit for an instant. Then the kettle will switch to standby mode and is again ready for use.

5. Pour the boiled or heated water into a prepared container, cup or mug. Make sure that the kettle remains in a vertical position when it is carried, particularly if it is filled all the way up to the maximum mark.
6. If you wish to refill the kettle, be careful not to scald yourself on the escaping steam or to burn yourself on the hot surface of the lid **A2** when opening or closing it.
7. After you finish using it, disconnect the power cord from the power socket. Empty the kettle and allow it to cool down.

CLEANING AND MAINTENANCE

1. Removing limescale deposits

- Limescale deposits inside the kettle may negatively affect its lifetime, so it is important to regularly remove it based on how frequently the kettle is used. During standard use (3 to 5 times per day), we recommend water scale deposits be removed:
 - once per month in areas with hard and very hard water;
 - once every two to three months in areas with soft and medium hard water.
- To remove limescale deposits it is possible to use:
 - 8% white vinegar, generally available in stores. Fill the kettle with 1 l of water and ¼ l of vinegar. Bring the solution to a boil and leave it to act in the kettle for 2 hours. Then empty the kettle and before further use, boil clean water in it four to five times.
 - citric acid. Boil 1.5 l of water in the kettle, into the boiled water, add 30 g of citric acid and allow the solution to act for about 30 minutes. Then empty the kettle and before further use, boil clean water in it four to five times.

2. Cleaning the outer surface

- Before cleaning, disconnect the power cord from the power socket. Empty all the contents from the kettle and allow it to cool down.
- To clean the external parts of the kettle, use a dry cloth or a cloth lightly dipped in a weak solution of neutral kitchen detergent. After applying the detergent, wipe the surface with a lightly damp cloth and then wipe dry.
- To clean the base, use only a dry cloth.
- For cleaning, never use steel wool, abrasive cleaning products, solvents, etc.



Attention:

Do not wash the kettle or its base **A5** under running water and do not submerge it or its base **A5** in water or another liquid.

TECHNICAL SPECIFICATIONS

Rated voltage range.....	220–240 V
Rated frequency.....	50/60 Hz
Rated power input.....	1 850–2 200 W
Nominal capacity.....	1.8l

We reserve the right to change text and technical specifications.

INSTRUCTIONS AND INFORMATION REGARDING THE DISPOSAL OF USED PACKAGING MATERIALS

Dispose of used packaging material at a site designated for waste in your municipality.

DISPOSAL OF USED ELECTRICAL AND ELECTRONIC EQUIPMENT



This symbol on products or original documents means that used electric or electronic products must not be added to ordinary municipal waste. For proper disposal, renewal and recycling hand over these appliances to determined collection points. Alternatively, in some European Union states or other European countries you may return your appliances to the local retailer when buying an equivalent new appliance.

Correct disposal of this product helps save valuable natural resources and prevents potential negative effects on the environment and human health, which could result from improper waste disposal. Ask your local authorities or collection facility for more details.

In accordance with national regulations penalties may be imposed for the incorrect disposal of this type of waste.

For business entities in European Union states

If you want to dispose of electric or electronic appliances, ask your retailer or supplier for the necessary information.

Disposal in other countries outside the European Union.

This symbol is valid in the European Union. If you wish to dispose of this product, request the necessary information about the correct disposal method from the local council or from your retailer.



This product meets all the basic requirements of EU directives related to it.