



EN ■ Variable temperature electric kettle

Translation of the original manual

Important safety instructions

READ CAREFULLY AND STORE FOR FUTURE USE.

- This appliance may be used by children 8 years of age and older, if they are properly supervised or have been informed about how to use of the product in a safe manner and understand the potential dangers. Cleaning and maintenance performed by the user must not be performed by children unless they are older than 8 years of age and under supervision. Keep the appliance and its power cord out of reach of children younger than 8 years of age.
- The appliance may be used by persons with reduced physical, sensory or mental capabilities or with a lack of experience and knowledge, if they are supervised or have been instructed to use the appliance in a safe manner and understand the potential dangers.
- Children must not play with the appliance.
- Cleaning and maintenance performed by the user must not be performed by unsupervised children.
- If the power cord is damaged, it must be replaced by the manufacturer, its service technician or by a similarly qualified person, as this will prevent a dangerous situation from arising.
- It is forbidden to use the appliance if it has a damaged power cord.
- The kettle is designed for domestic use and similar places such as:
 - staff kitchens in stores, offices and other workplaces;
 - agricultural farms;
 - hotel or motel rooms and other living areas;
 - bed and breakfast establishments.
- If the kettle is overfilled, then boiling water could splash out.
- Only use the kettle with the base that was supplied with it.
- Take care not to spill water on to the connector when placing the kettle on to the base and when taking it off the base.
- Wipe any surfaces that come into contact with food using a soft sponge lightly dampened in clean warm water.




Attention:

Incorrect use may lead to injuries.

- The surface of the heating element and kettle body is remains hot after use due to residual heat. Do not touch the hot surface.

- When filling the kettle, make sure that the water level covers at least the minimum mark and also that it does not go over the maximum mark.
- Do not wash the kettle or its base under running water and do not submerge it or its base in water or another liquid.
- Before connecting the kettle to a power socket check that the nominal voltage matches the electrical voltage in the socket.
- Connect the kettle only to a properly grounded socket.
- Do not place the kettle on window sills, kitchen sink drainboards or unstable surfaces. Always place it on a stable, even and dry surface.
- Do not place the kettle on equipment or devices that are sources of heat.
- Never use the kettle in the near vicinity of a bath, shower or swimming pool.
- Use the kettle exclusively for boiling drinking water. Do not use it to heat other liquids or foodstuffs.
- Always take the kettle off the base before filling it.
- Check that the lid is securely closed before starting the kettle. Do not open the lid or handle it in any way while the water is boiling.
- Use the handle for lifting and carrying the kettle.
- Be especially careful when pouring water out of the kettle to avoid scalding by the boiling water or steam.
- Always disconnect the kettle from the power socket when leaving it without supervision, when not using it and before moving or cleaning it.
- Clean it according to the instructions in chapter Cleaning and maintenance.
- Disconnect the kettle from the power socket by pulling on the plug, never pulling on the power cord. Otherwise, this could damage the power cord or the socket.
- To avoid the danger of injury by electrical shock, do not repair the kettle yourself or make any adjustments to it. Have all repairs or adjustments performed at an authorised service centre. By tampering with the appliance, you risk voiding your legal rights arising from unsatisfactory performance or quality warranty.

A



Variable temperature electric kettle

EN User's manual

Variable temperature electric kettle

Prior to using this appliance, please read the user's manual thoroughly, even in cases, when one has already familiarised themselves with previous use of similar types of appliances. Only use the appliance in the manner described in this user's manual. Keep this user's manual in a safe place where it can be easily retrieved for future use.

We recommend saving the original cardboard box, packaging material, purchase receipt and responsibility statement of the vendor and warranty card for at least the duration of the legal liability for unsatisfactory performance or quality. In the event of transportation, we recommend that you pack the appliance in the original box from the manufacturer.

DESCRIPTION OF THE KETTLE

A1 Lid	A6 Display
A2 Handle	A7 Plus (+) button
A3 Base with a central connector	A8 KEEP WARM button
A4 ON/OFF button	A9 Glass kettle with water level mark
A5 Minus (-) button	A10 Stainless steel strainer
	A11 Spout

BEFORE FIRST USE

Remove all packaging material from the electric kettle and its base A3. Fill the kettle with clean water up to the maximum water mark. Boil the water and empty the contents of the kettle. Repeat this process 2 to 3 times. Now the kettle is ready for operation.



Note:

To boil water in the electric kettle proceed according to the instructions in chapter Using the electric kettle.

USING THE ELECTRIC KETTLE

Heat Water to 100 °C

Set the required power cord length and push it into the groove in the base A3. Place the base A3 on a stable, even and clean surface.

Remove the lid A1 and fill the kettle with the required amount of water. Put the lid A1 back on.



Attention:

The water level must reach at least the minimum mark (0.5 l) but must not exceed the maximum mark (1.0 l). Do not fill the kettle when it is placed on the base A3.

Place the kettle on the base A3. Insert the power plug into a power socket. A sound is made. Press the ON/OFF button A4 and the display A6 will show "100 °C". After approximately 5 seconds the heating process will start automatically. The increasing temperature inside the kettle will be shown on the display A6.

When the water comes up to temperature, a sound will be made and the kettle will turn off automatically. The display A6 will remain lit.



Note:

The display A6 will turn off after approximately 2 hours of inactivity.



Attention:

Do not turn on the kettle when it is empty. The incorrect use of the kettle may negatively affect its lifetime. If you accidentally turn on the kettle without water, the thermostat will, after reaching a certain temperature, interrupt the electric circuit. The kettle can be used again after several minutes, once the heating bottom has cooled down.

When the water comes to a boil, a sound will be made and the kettle will turn off automatically.



Note:

The operation of the kettle can be stopped at any time by pressing the ON/OFF button A4.

Pour the boiled water into a prepared container, cup or mug. Make sure that the kettle remains in a vertical position when it is carried, particularly if it is filled all the way up to the maximum mark.

If you wish to refill the kettle, be especially careful when removing the lid A1 to avoid scalding by the escaping steam.

After you finish using it, disconnect the power cord from the power socket. Empty the kettle and allow it to cool down.



Note:

Before turning on the kettle, always make sure that the stainless steel strainer is taken out.

Heating water to a required temperature

The kettle enables water to be heated to a set temperature in the range between 60 °C and 100 °C. Press the ON/OFF button A4 and the display A6 will show "100 °C". Use the +/- buttons to set the desired temperature. After approximately 5 seconds, the heating process will start automatically. The increasing temperature inside the kettle will be shown on the display A6.

When the water comes up to temperature, a sound will be made and the kettle will turn off automatically. The display A6 will remain lit.



Attention:

This electric kettle is not calibrated for scientific or laboratory purposes. The actual temperature inside the kettle may differ by +/- 5 °C from the set water temperature.

Keep Warm function

The Keep Warm function can be set in two ways:

1. Press the KEEP WARM button A8 and the display A6 will show "60 °C". Use the +/- buttons to set the desired temperature to which the water should be heated and at which it should be maintained. After approximately 5 seconds, the heating process will start automatically. The increasing temperature inside the kettle will be shown on the display A6.

When the water comes up to temperature, the kettle will beep and automatically switch to the maintain set temperature mode.

2. Press the ON/OFF button A4 and the display A6 will show "100 °C". Use the +/- buttons to set the desired temperature.

Then press the KEEP WARM button A8 and the display A6 will show "60 °C". Use the +/- buttons to set the desired temperature to which the water should be heated and at which it should be maintained.

After approximately 5 seconds, the heating process will start automatically. The increasing temperature inside the kettle will be shown on the display A6.

When the water comes up to temperature, the kettle will beep and automatically switch to the maintain set temperature mode.

The kettle will maintain the set temperature in the Keep Warm mode until it is taken off the base, however no longer than 2 hours. Then the kettle will turn off.



Note:

When the kettle is in the Keep Warm mode, it will turn on in regular intervals to heat up the water to the set temperature when the water temperature in the kettle falls. This is normal.



Attention:

If you selected the Keep Warm function for a temperature of 100 °C, for safety reasons the kettle will maintain a temperature of 90 °C to prevent the water from boiling off, resulting in subsequent damage to the kettle.

Brewing tea

After boiling water, you can also brew your tea inside the kettle.

Pour the required amount of tea leaves into the tea strainer. Heat the water in the kettle – see chapter "Heat Water to 100 °C" or "Heating water to a required temperature".

When the water reaches the desired temperature, carefully remove the lid A1 from the kettle and place the strainer with the tea leaves into it. Allow it to brew as required. Adhere to the temperature and brewing time provided on the tea packaging.

CLEANING AND MAINTENANCE

Before cleaning it, make sure that the kettle is turned off, disconnected from the power socket, and allow it to cool down.

To clean the external parts of the kettle, use a dry cloth or a cloth dipped in a weak solution of neutral kitchen detergent. After applying the kitchen detergent, wipe the surface with a lightly damp cloth and then wipe dry.

To clean the base A3 use only a dry cloth.

Never use solvents, abrasive cleaning agents, etc.



Attention:

To prevent injury by electrical shock, bodily injury or another dangerous situation, do not submerge the electric kettle, its base or the plug of the power cord in water or any other liquid.

Removing lime scale deposits

Limescale deposits inside the kettle may negatively affect its lifetime, so it is important to regularly remove them based on how frequently the kettle is used. During standard use (3 to 5 times per day), we recommend limescale deposits be removed:

- once per month in areas with hard and very hard water;
 - once every two to three months in areas with soft and medium hard water.
- To remove limescale deposits it is possible to use:
- 8% white vinegar, generally available in stores. Fill the kettle with 1 litre of water and ¼ litre of vinegar. Bring the solution to a boil and leave it to act in the kettle for 2 hours. Then empty the kettle and before further use, boil clean water in it four to five times.
 - citric acid. Boil 1 l of water in the kettle, then add 30 g of citric acid into the boiled water, and allow the solution to act for about 30 minutes. Then empty the kettle and before further use, boil clean water in it four to five times.

Storage

When not using the kettle for an extended period of time, disconnect the plug from the power socket and allow it to cool down. Clean it according to the instruction above. Before storing it, check that the kettle is clean and dry.

Store it in a dry, clean and well-ventilated location not exposed to extreme temperatures and out of children's reach.

TECHNICAL SPECIFICATIONS

Rated voltage range	220 – 240 V~
Rated frequency.....	50/60 Hz
Rated power input	1,850 – 2,200 W
Capacity	1.0 l

We reserve the right to change text and technical specifications.

INSTRUCTIONS AND INFORMATION REGARDING THE DISPOSAL OF USED PACKAGING MATERIALS

Dispose of used packaging material at a site designated for waste in your municipality.

DISPOSAL OF USED ELECTRICAL AND ELECTRONIC EQUIPMENT

 This symbol on products or original documents means that used electric or electronic products must not be added to ordinary municipal waste. For proper disposal, renewal and recycling hand over these appliances to determined collection points. Alternatively, in some European Union states or other European countries you may return your appliances to the local retailer when buying an equivalent new appliance.

 Correct disposal of this product helps save valuable natural resources and prevents potential negative effects on the environment and human health, which could result from improper waste disposal. Ask your local authorities or collection facility for more details.

In accordance with national regulations penalties may be imposed for the incorrect disposal of this type of waste.

For business entities in European Union states

If you want to dispose of electric or electronic appliances, ask your retailer or supplier for the necessary information.

Disposal in other countries outside the European Union.

This symbol is valid in the European Union. If you wish to dispose of this product, request the necessary information about the correct disposal method from the local council or from your retailer.

 This product meets all the basic requirements of EU directives related to it.