



EN ■ User Manual

CZ ■ Uživatelská příručka

SK ■ Používateľská príručka

HU ■ Felhasználói kézikönyv

PL ■ Podręcznik użytkownika

Weather Station with Wireless Sensor

Meteorologická stanice s bezdrátovým snímačem

Meteorologická stanica s bezdrôtovým snímačom

Meteorológiai állomás vezeték nélküli érzékelővel

Stacja pogodowa z czujnikiem bezprzewodowym

We thank you for the purchase of our Color Display Weather Station. It has been designed and constructed using innovative components and techniques to enable the perfect display by this device. This unit is also equipped with an outdoor sensor. Please read the entire instruction manual before using the product and then save it for future reference. We reserve the right for any errors in text or images and any necessary changes made to technical data.

Things to consider:.

1. Other wireless equipment using the same frequency band can reduce the transmission range.
2. The range of all wireless equipment depends on the type of obstacles located between the transmitter and the receiver (e.g. a concrete wall will interfere with the signal much more than a plasterboard wall).

If you experience problems, try the following:

1. Turn off any other existing wireless equipment to check whether this is the cause of the problem.
2. Move any other existing wireless equipment. Shorten the distance between the sending and receiving devices and reduce the number of obstacles(walls, furniture,etc.) between them.
3. Try removing and reassembling batteries, if the batteries are old, try new ones.

SAFETY AND GUIDE


- Do not clean any part of the product with benzene, thinner or other solvent chemicals. If necessary, clean it with a soft cloth.
- Do not dismantle or modify the product in any way.
- Never immerse the product in water, It will damage the product.
- Do not subject the product to extreme force, shock, or fluctuations in temperature or humidity.
- Do not tamper with the internal components.
- Do not use used batteries .
- Do not use different types of batteries alkaline, standard or rechargeable batteries with this product.
- Remove the batteries if storing this product for a long period of time, otherwise the battery might damage the product.
- Do not dispose of this product as unsorted municipal waste, it's necessary to separately collect it for special treatment.
- Do not place the main unit in rain or moisture.The transmit range depends on the type of obstacles located between the transmitter and the receiver (e.g. a concrete wall will interfere with the signal much more than a plasterboard wall).
- Be sure the sensor is mounted vertically, to allow moisture to drain out properly. Place out of direct sunlight & ensure the sensor is well-ventilated.
- The distance between main unit and sensors should be at least 5~ 6.5 feet (1.5~2 meters) away from any interfering sources such as computer monitors or TV sets.
- The main unit stay away from the metal window frames.
- Please do not use other electrical products such as headphones or microphone operating on the same signal frequency. (433.92MHz), neighbors using electrical devices operating on the same signal frequency can also cause interference.
- Place the main unit in a dry area, free of dirt and dust. To ensure accurate temperature measurement, place out of direct sunlight and away from heat sources or vents.

Package Contents

- 1 x Digital Weather Station
 - 1 x Remote Sensor
 - 1 x User Manual
 - 1*DC Adaptor
- (Batteries are not included)

MAIN UNIT INSTALLATION


- Remove the protective film that is applied to the LCD screen prior to using the product.
- Plugged in with power adapter and use, battery-power is optional, since previous setting will be reset when plugged out, we recommend install the batteries for the base station.
- Base station can stand upright on the table.



SENSOR INSTALLATION

Base station supports up to 3 sensors connection, the sensor switch is located inside the battery compartment, it can be switched 1,2,3, matching the info of Channel 1, Channel 2, Channel 3 that synchronize on the OUTDOOR position.

1. Remove the battery compartment cover, chose the channel (1,2,3)by switching the channel shift.
2. Insert 2 x AA batteries matching the correct polarity (+ and -), the red led light will flash for once, then assemble the battery compartment.
3. Put the sensor the position you desire.



Low Battery Indicator

When battery power for main unit is lower than 3.6V, or when the power for remote sensor is lower than 2.5V, the low battery indicator will display on the LCD.

When it is powered by DC adaptor, the batteries are for memory function. If the low battery indicator for main unit still shows, that means the batteries' power for main unit is lower than 3.6V, please check the batteries situation.

To avoid batteries runs out, getting rotten and damage the units. please change batteries on time when low battery indicator appear.


Please use alkaline dry batteries, do not use rechargeable batteries.

Initialization



1. Install batteries for main unit first, then install batteries for Remote sensor, Plug in the adaptor
2. After power on, LCD will display full indicator for 3 seconds, and in the meanwhile, temperature sensor and humidity sensor inside will detect indoor temperature & humidity, and then it will start to receive outdoor signal which last for max 3 minutes.

- Time: 24-hour format, 1st Jan, 2022
- Default language: GER
- Date format: D-M
- Temperature unit: °C
- Time difference: 0 time zone
- Alarm time: ALARM1: AM 6 : 30
- Weather: cloudy

OVERVIEW




- | | |
|---------------------------------------|--------------------------------------------------------------------|
| 1. Freezing Alert | 13. Comfortable Indicator(Sensor) |
| 2. Alarm | 14. Moon Phase |
| 3. 12/24hours-AM/PM | 15. Barometer Pressure Value |
| 4. Time | 16. Barometer Pressure Bar |
| 5. Snooze | 17. Weekday |
| 6. RCC | 18. Month and Date |
| 7. Rolling display of 3 channels | 19. Comfortable Indicator(Main Unit) |
| 8. Outdoor temperature and humidity | 20. Max Min record for outdoor temperature and humidity in 24hours |
| 9. Temperature Trend | 21. HI &Lo Temperature Alert (Main Unit) |
| 10. HI &Lo Temperature Alert (Sensor) | 22. Indoor temperature and humidity |
| 11. Low battery Indicator | |
| 12. Humidity Trend | |



- 23. Buttons: SET, ▲/CH ; ▼/RCC; MEM; ALERT; ALARM
- 24. DC Jack
- 25. Stand
- 26. Touch Button

SENSOR




- 1.LED light
- 2.Battery compartment Cover
- 3.Hanging hole
- 4.Channel shift
- 5.Rope hanging hole

Waterproofing for daily use, lever: IP54.

When the red led light flash, it is sending signal to main unit.

Be sure our sensor is mounted vertically, to allow moisture to drain out properly. Keep out of direct sunlight & ensure the sensor is well-ventilated.

DC ADAPTOR



FEATURES

- Weather forecast with 5 status: sunny, partly cloudy, cloudy, rainy, and snowy
- Weekday display in 7 languages
- Freezing Alert Function
- Time and Calendar(Date/Month/Year)
- RCC-DCF automatic time adjustment
- 12/24 hours format switchable
- Alarm with snooze function
- Indoor temperature and humidity
- Outdoor temperature and humidity
- Support up to 3 sensors(1 included)
- Function auto scrolling measured data of all 3 outdoor sensors
- Max/ Min memory records for all indoor and outdoor temperature and humidity
- Comfortable Indicator for all indoor and outdoor temperature and humidity
- Temperature & humidity trend display
- Indoor &Outdoor temperature HI & LO alert (independent setting).
- Barometer pressure bar and value display
- Moon Phase
- 3-mode brightness: Bright/Dim/Off
- C/F(Celsius/Fahrenheit) switchable
- Max/ Min memory records
- Low battery indicator
- Tone on/off function
- Transmission range: up to 80 meters in open area
- Table standing
- Sensor Transmission Frequency:433.92MHZ
- Main Unit Power: 3*1,5V type AA (Batteries Not Included) & 5V 1.2A DC Adaptor(Included)
- Sensor Power:2*1,5V type AA(Batteries Not Included)

BUTTONS FUNCTION

SET

- In normal time display mode, press and hold the SET button for 3 seconds to enter the time setting ▲/CH.
- In time display mode, press the ▲/CH button to check different channels.
- In time display mode, press and hold the ▲/CH button to clear all channel IDs and re-register new IDs.
- In Setting Mode, single press ▲/CH button to increase by 1, long press to increase by 8 steps per second.

▼/RCC

- In normal time display mode, press and hold the ▼/RCC button for 2 seconds to turn on the RCC function.
- In RCC receiving mode, press the ▼/RCC button to turn off the RCC receiving function
- In Setting Mode, press the ▼/RCC button to decrease by 1, long press to decrease by 8 steps per second.

MEM

- In time display mode, press the MEM button to check the maximum/minimum temperature and humidity values within 24 hours.
- In max/min checking mode, press and hold the MEM button for 2 seconds to manually clear the maximum/minimum values.

ALERT

- In normal display mode, press to check the HI&LO temperature alert, and short press the ▲/CH or ▼/RCC button to turn on/off the alarm icon (the default upper limit of the temperature alarm is 35 degrees, and the default lower limit is 10 degrees)
- In normal display mode, press and hold for 3 seconds to enter indoor/outdoor temperature alarm setting mode
- When the temperature reaches the set alarm range, the buzzer will sound BI BI BI BI in one group. If there is no button, it will sound one group every full minute until it exits the alarm temperature range.
- If you press any button during the temperature alarm, the alarm sound will stop, but the alarm icon will continue to flash at a frequency of 1HZ until it exits the alarm range.

ALARM

- In normal time display mode, press the ALARM button to view the alarm time and switch the alarm symbol on and off
- In normal time display mode, press and hold the ALARM button for 3 seconds to enter the alarm setting.

SNOOZE/LIGHT

- When the alarm is sounding, press the SNOOZE/LIGHT button to delay the alarm for 5 minutes, and any other button to stop the alarm.
- In any mode, press the SNOOZE/LIGHT button to enter the brightness level setting
- In any setting mode, single press the SNOOZE/LIGHT button to return to the normal display mode

TIME SETTING MODE

- In standard mode, press and hold SET button for 3 seconds to enter time setting
- The setting item flash at a frequency of 1HZ. Short press the MODE button to select the setting items. The order is: Language →button tone ON/OFF→RCC ON/OFF(ON:ZONE±12HR)→12/24HR→Hour→Minute→Year→DM/MD→Month→Day→C/F→Barometric pressure unit→Weather →exit
- In time setting mode, when the setting item flashes at 1HZ frequency, short press the UP button to add 1, and press and hold the UP button to quickly add up at 8 steps/second.
- In the time setting mode, when the setting item flashes at a frequency of 1HZ, short press the DOWN button to decrease by 1, and press and hold the DOWN button to quickly decrease at 8 steps/second.
- In time setting mode, if you do not operate for 20secs or press the SNOOZE button during the setting process, you can save the current setting value and exit the time setting.

7 Languages of Weekday

Language	German	English	Italian	French	Dutch	Spanish	Denish
ABBR.	GE	EN	IT	FR	DU	SP	DA
Monday	MO	MO	LU	LU	MA	LU	MA
Tuesday	DI	TU	MA	MA	DI	MA	TI
Wednesday	MI	WE	ME	ME	WO	MI	ON
Thursday	DO	TH	GI	JE	DO	JU	TO
Friday	FR	FR	VE	VE	VR	VI	FR
Saturday	SA	SA	SA	SA	ZA	SA	LO
Sunday	SO	SU	DO	DI	ZO	DO	SO

ALARM SETTING MODE

In the normal display interface, press and hold the ALARM button for 2 seconds to enter the alarm time setting mode. The setting sequence is: hours → minutes → exit.

- Snooze time is 5 minutes.
- When the setting item flashes at 1HZ frequency, short press the +/CH button to add 1, and long press the +/CH button to quickly accumulate in 8 steps/second.
- When the setting item flashes at 1HZ frequency, short press the -/WAVE key to decrease by 1, and long press the -/WAVE key to quickly decrease in 8 steps/second.
- If no operation is performed for 20 seconds, save the current setting status and exit the alarm time setting.

ALARM MODE

Alarm time: 2 minutes

Alarm Period: 0-10 seconds: BI once every second
 10-1minute: BI BI twice per second
 21-30 seconds: BI BI BI three times per second
 31-11minute: continuous BI BI BI BI beep

When the alarm sounds, press the SNOOZE/LIGHT button to enter snooze (5 minutes). Press any other button to stop the alarm.

BACK LIGHT

When DC powered, backlight brightness is 100%, 50%, 10%, OFF,

- When DC power supply, after power-on, the default backlight is 100% bright and always on, press the SNOOZE/LIGHT button and the backlight will cycle between high brightness 100%→50%→10%→OFF.
- When Battery-powered, after power-on, the default backlight is 100% on for 20secs. The backlight is off by default when the alarm sounds. After pressing the button to stop the alarm, the backlight turns off automatically after one minute.

Indoor/Outdoor Temperature and Humidity and Trend

Indoor temperature range: -9.°C~50°C



Outdoor temperature range: -40°C~60°C

LL.L & HH.H will display when out of range

Indoor/outdoor humidity detection range: 1% to 99%;

if it is higher than 99%, it will display 99%, if it is lower than 1%, it will display 1%

2.Trends:

- Trends Icon will not display at the moment of powering on.
- The trend  will display, when the temperature increase 1°C compared to last data, or increase 1°C in 1 hour;
- The trend  will display, when the humidity value increase 5% compared to last data, or increase 5% in 1 hour vice the verse for decrease trends. When the increase/decrease is less than 1°C or 5% in 1 hour, no trend icon will display.

MEMORY

1. Under normal time displaying mode, press **MEM** button to check the 3 channel indoor and outdoor temperature and humidity, the record sequence is :Indoor/outdoor maximum temperature&humidity→Indoor/outdoor minimum temperature&humidity. No operation in 6 seconds, it will return to current temperature &humidity display.

2. Max/Min:

The maximum/minimum records will be cleared automatically at 00:00 everyday. Or manually clear the max/min record by holding **MEM** at Time Display mode. It will clear the record, display --, and then display the current value.

Atmospheric Pressure

- 3 UNITS for choice: hPa/mb, inHg, mmHg
- Range: 850-1050 hPa
- Atmospheric pressure is updated and tested every hour, and the air pressure bar is updated at the same time.
- Record the atmospheric pressure value in the past 1, 2, 3, 6, and 12 hours, and compare it with the current pressure value to form a trend bar and display it.
- From right to left, one column is displayed every second, and the dynamic display is continuously cycled.

COMFORT LEVEL INDEX

Comfort level displays with 3 status: DRY, GOOD, WET

Comfort Level	Humidity Range
Dry	1-39%
Good	40-70%
Humid	≥ 71%

Frost Alert


When the outdoor display temperature of the current RF channel is within the range of 0~2.9°C, the frost point alarm symbol “❄️!” flashes;

when temperature of the outdoor channel is lower than 0°C, the frost and snow symbol ❄️! displays all the time, when temperature is higher than 2.9°C the freezing point symbol ❄️! disappear.






Moon phase

MOON PHASE displays the moon phase level, and the moon phase level is divided into 12 levels, as shown in the figure below.

It will display automatically once the unit receives or set with date information.





WEATHER FORECAST

WEATHERICON					
Description	Sunny	Partly Cloudy	Cloudy	Rainy	Snowy

- Weather forecast in 12+ Hour: Sunny, Partly Cloudy, Cloudy, Rainy, Snowy
- The weather icon displays are based on the hourly calculation of indoor/outdoor temperature & humidity. The forecast station predict weather conditions for the next 12 hours with 70-75% accuracy. The remote sensor should be put on the outside to have accurate outdoor data. Or it will effect the accurate of weather forecast.
- The default display weather is partly cloudy, the main unit will calibrate the weather report in 1-2 weeks with the temperature and humidity data changes.
- The remote sensor should be place outside to get accurate outdoor data or it will effect the accurate of weather forecast.

RF-OUTDOOR TERPERATURE AND HUMIDITY

After the power is turned on, main unit is powered on or reset, if all three channels receive signals within 3-minute reception time, the reception will close immediately, as long as there is still one channel that has not received successfully, the RF receiving mark is still flashing. During long-term reception, the RF signal sign “” flashes at a frequency of 1Hz. After the RF signal is successfully received, the symbol “” will be displayed all the time.

If the receiver only receives 1 or 2 channels within 3 minutes, the channel that does not receive a signal will no longer be automatically opened for reception in the future, and only the channel that has been paired and registered will be received, unless it is powered on again, reset or manually forced pairing to receive all channels

CHANNEL & SENSOR OPERATION


1. The weather station supports max connection with up to 3 sensors.
2. Remove the battery cover of sensor and slide CH switch to CH1/CH2/CH3, make sure each sensor is assigned to a different CHANNEL number.
3. It is recommended to put CH1 sensor in outdoor for more accurate weather forecast, and put other sensors in your desired area.
4. In standard mode, Press **▲/CH** button to check the outdoor temperature and humidity of channel 1/2/3. When you switch to the mode, the display will automatically loop 3 sensor' data.If you want to reset all the data of sensors, press and hold **▲/CH** button 3 seconds, and it will reconnect with the sensors.



Note:



When there is a conflict between RF, RCC and alarm sound, the priority order is: Alarm → RCC → RF. When the RF is on reception for 3 minutes, it is interrupted by RCC or interrupted by an alarm. After the RCC reception is completed or the alarm is completed, the RF is turned on again for 3 minutes.

RCC Function

During Time setting, if RCC is set OFF, the RCC function is turned off permanently, until it is set ON again.


After power-on or reset, it will automatically enters the RCC receiving mode. The triangular tower symbol “” displays and flashes at a frequency of 1Hz. If there is a connection during RCC reception,

After receiving a valid signal, the triangular tower symbol “” displays statically, and the signal wave symbol “” flashes at a frequency of 1Hz. If the signal is received during valid reception,

If the signal is suddenly interrupted, the signal wave symbol “” will not display, and the triangular tower symbol “” will be displays and flash until a valid signal is received again.

Switch to the previously valid display mode.

The RCC reception time is 7 minutes. If the RCC reception is successful within 7 minutes, the time

displays on the unit the reception will be exited immediately and the RCC symbol “” will displays all the time, indicating that the RCC reception is successful.

Automatically receive RCC function: Regardless of whether the RCC signal is received or not, it will automatically enter the RCC reception at 1:00, 2:00, 3:00, 4:00, and 5:00 every morning. The unit will receive signal on 1:00, 2:00 and 3:00, if 3:00 is not received successfully, the receiving is turned on in turn, as long as there is 1 successful reception. If it succeeds, the receiving will not be turned on for the next few times, no matter whether the receiving is successful or not

In standard mode, press and hold the **▼/RCC** button for 3 seconds to manually enter the RCC receiving mode. Press the **▼/RCC** button again to exit reception.

If there is no reception within 7 minutes, it will automatically exit RCC reception and continue to run at the original time, and then every 3 hours at 0:00, 3:00, 6:00,9:00, 12:00, 15:00, 18:00, 21:00 automatically

RCC reception will be turn on. It does not follow the early morning reception rules. As long as the reception is successful once, it will become the early morning reception rules.

- When the time zone setting is not 0 , the time will automatically changes with the time zone.
- When there is a conflict between RF, RCC the priority order is RCC → RF
- When the RF reception is interrupted by RCC. It will be turn on again after the RCC reception is completed.

PRECAUTIONS

- Do not clean any part of the product with benzene, thinner or other solvent chemicals. When necessary, clean it with a soft cloth.
- Never immerse the product in water. This will damage the product.
- Do not subject the product to extreme force, shock, or fluctuations in temperature or humidity.
- Do not tamper with the internal components.
- Do not mix new and old batteries or batteries of different types.
- Do not mix alkaline, standard or rechargeable batteries with this product.
- Remove the batteries if storing this product for a long period of time.
- Do not dispose of this product as unsorted municipal waste. Collection of such waste separately for special treatment is necessary.

ADAPTER TECHNICAL SPECIFICATIONS

Manufacturer's name or trade mark,
commercial registration number and
address:

DONGGUAN SHIJIE HUAXU ELECTRONICS FACTORY,
Commercial Registration Number: 440429543,
Address: No.200, Technology East Road ,Shijie
TownDongguan City,Guangdong, P.R.China

Model identifier:

HX075-0501200-AG-001

Input voltage:

AC100 - 240V

Input AC frequency:

50/60Hz

Output voltage:

DC5.0V

Output current:

1.2A

Output power:

6.0W

Average active efficiency:

≥75.00%

Efficiency at low load (10 %):

71.17%

No-load power consumption:

≤0.1W

TECHNICAL SPECIFICATIONS

- Weather Forecast Icon (Sunny, Partly Cloudy, Cloudy, Rainy, Snowy)
- 12 ~ 24 Hour Forecast Based on Changing Air Pressure and Temperature
- Indoor Temperature and Humidity Reading with Trend Indicator
- Outdoor Temperature and Humidity Reading with Trend Indicator
- Radio Controlled Clock by Signal DCF77 (Manual Setting Possible)
- Barometric Pressure Value
- Bar Chart for Pressure Changes (-1, -2, -3, -6, -12 hours)
- Digital Time, Date and Weekday
- Moon Phase
- Comfort Level Indication (3 Levels)
- Outdoor Temperature High / Low Alert Function
- Frost Alert for Outdoor Channel
- Max / Min Memory Records (24 h)
- Alarm and Snooze Function
- Indoor Temperature Range: -10°C to +50°C
- Outdoor Temperature Range: - 40°C to +60°C
- Indoor and Outdoor Humidity Range: 1% to 99% RH
- 12 / 24 Hours Selectable Format
- Temperature Display with °C / °F Selectable
- 3 Level Display Brightness: Hi / Lo / Off
- Placement on Desk
- Low Battery Indicators (for Main Unit and Outdoor Sensor)
- Support up to 3 Sensors
- Function Auto Scrolling Measured Data of All Three Outdoor Sensors
- 1 Sensor Included (SWS TH3600-4500-4900)
- Transmission Between Main Unit and Sensor up to 80 m (in Open Area)
- Sensor Transmission Frequency: 433.92 MHz
- Power Adaptor of Main Unit: DC 5 V / 1200 mA (Included), Consumption: 6 W
- Battery Back-Up of Main Unit: 3 x 1,5 V Type AA (Batteries Not Included)
- Power of Sensor: 2 x 1.5 V Type AA (Batteries Not Included)
- Dimensions of Main Unit: (w / h / d) 200 x 129 x 30 mm
- Weight of Main Unit: 337 g

INSTRUCTIONS AND INFORMATION ON THE DISPOSAL OF DISCARDED PACKAGING MATERIALS

Take the packaging material to a collection yard for disposal.

DISPOSAL OF DISCARDED ELECTRICAL AND ELECTRONIC EQUIPMENT



This symbol on the product, accessory or packaging indicates that the product must not be treated as normal household waste. Please dispose of this product in a collection yard designated for the recycling of electrical and electronic equipment. In some EU countries or in some European countries, you can return your products to your local retailer when you buy an equivalent new product. Correct disposal of this product helps save valuable natural resources and prevents possible adverse impacts on the environment and human health that might be caused by improper waste disposal. Please contact your local authority or the nearest waste collection yard for further details. Improper disposal of this type of waste may be subject to a legal fine.

For companies in the European Union

If you need to dispose of electrical or electronic equipment, ask your dealer or supplier for the necessary information.

Disposal in countries outside the European Union

To dispose of this product, please ask your local authorities or dealer for the necessary information on correct disposal.



This product complies with EU requirements.

FAST ČR, a. s. hereby declares that the radio device type SWS 4900 complies with Directive 2014/53/EU. For full version of the EU declaration of conformity, please refer to the website: www.sencor.com

Changes in the text, design and technical specifications may be made without prior notice and we reserve the right to make such changes.

The original version is in Czech.

Manufacturer: FAST ČR, a.s., U Sanitasu 1621, Říčany 251 01, Czech Republic

Authorized service centers: Visit www.sencor.com for detailed information about authorized service centers.

SENCOR®

EN Warranty conditions

Warranty card is not a part of the device packaging.

This product is warranted for the period of 24 months from the date of purchase to the end-user. Warranty is limited to the following conditions. Warranty is referred only to the customer goods using for common domestic use. The claim for service can be applied either at dealer's shop where the product was bought, or at below mentioned authorized service shops. The end-user is obligated to set up a claim immediately when the defects appeared but only till the end of warranty period. The end user is obligated to cooperate to certify the claiming defects. Only completed and clean (according to hygienic standards) product will be accepted. In case of eligible warranty claim the warranty period will be prolonged by the period from the date of claim application till the date of taking over the product by end-user, or the date the end-user is obligated to take it over. To obtain the service under this warranty, end-user is obligated to certify his claim with duly completed following documents: receipt, certificate of warranty, certificate of installation.

This warranty is void especially if apply as follows:

- Defects which were put on sale.
- Wear-out or damage caused by common use.
- The product was damaged by unprofessional or wrong installation, used in contrary to the applicable instruction manual, used in contrary to legal enactment and common process of use or used for another purpose which has been designed for.
- The product was damaged by uncared-for or insufficient maintenance.
- The product was damaged by dirt, accident of force majeure (natural disaster, fire, and flood).
- Defects on functionality caused by low duality of signal, electromagnetic field interference etc.
- The product was mechanically damaged (e.g. broken button, fall).
- Damage caused by use of unsuitable media, fillings, expendable supplies (batteries) or by unsuitable working conditions (e.g. high temperatures, high humidity, quakes).
- Repair, modification or other failure action to the product by unauthorized person.
- End-user did not prove enough his right to claim (time and place of purchase).
- Data on presented documents differs from data on products.
- Cases when the claiming product cannot be indentified according to the presented documents (e.g. the serial number or the warranty seal has been damaged).

Manufacturer:

FAST ČR, a.s., U Sanitasu 1621, Říčany 251 01, Czech Republic

Visit www.sencor.com for detailed information about authorized service centers.

The original version of the instructions is in the Czech language, other language versions are made by the appropriate translation.

