

CERAMIC HEATER

INSTRUCTION MANUAL

EN



SENCOR®

SFH 9010/SFH 9011

Prior to using this appliance, please read the user's manual thoroughly, even in cases, when one has already familiarised with previous use of similar types of appliances. Use the appliance only as described in this instruction manual. Store the instruction manual in a safe place for future reference.

We recommend saving the original shipping cardboard box, packaging material, receipt and warranty for the period of the warranty at minimum. In case of transportation, pack the product using the original packaging materials only.

CONTENTS

IMPORTANT SAFETY INSTRUCTIONS	2
DESCRIPTION	3
OPERATION	3
CLEANING AND MAINTENANCE	3
TECHNICAL DATA	4
DISPOSAL OF USED ELECTRICAL & ELECTRONIC EQUIPMENT	4

IMPORTANT SAFETY INSTRUCTIONS

- Remove the packing and make sure that the appliance is intact. Do not leave packaging materials like bags and staples within reach of children.
- Before switching on appliance check if the electrical voltage and frequency of the circuit corresponds to those indicated on the appliance. The power outlet has to be provided with an earth-wire.
- Do not connect the appliance to an extension cable or a multiplug.
- Use the appliance only for the mentioned purpose, namely as a heater for domestic use.
- The use of every electrical appliance calls for the awareness of some basic rules, such as:
 - never touch the appliance with wet or damp hands or feet.
 - never expose the appliance to atmospheric conditions (rain, sun etc.).
- The appliance must be always placed on a flat and stable surface.
- Do not use the heater near bath-tubs, showers, wash-basins or swimming-pools.
- Do not put the cable on the appliance when it is still warm.
- Do not switch on the heater near pieces of furniture, curtains, shelves or other flammable objects.
- Never operate the appliance immediately below an outlet.
- Do not insert any objects into the front safety grille for air outlet or rear air inlet. You may cause an electric short – circuit, fire or damage of the product.
- Do not use the unit when sleep if use make sure the unit is far away of particles such as textile, bedding etc. to avoid accident.
- Never touch the protector on the front to avoid burn when the unit is in operation..




- **WARNING!** Do not cover the appliance with any object to avoid overheating.
- **ATTENTION:** Do not connect the appliance to a device switching the appliance automatically on such as a time switch to avoid overheating risks when the heater is moved or covered.
- Switch the appliance off and unplug it when not in use.
- This appliance is not intended to be mounted on the wall.
- Make sure that the power cord is not in the contact with hot or sharp objects.
- Do not damage and do not kink the power cord.
- In case the power cord is damaged send it to the nearest after sale service recommended by the manufacturer for the replacement.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they will not play with the appliance.
- Do not expose any person or animals to the hot air for long time. This can affect their health.
- Before cleaning the appliance or carrying out any maintenance switch off the whole system.
- To protect against electric shock, never immerse the heater in water or splash water on it.
- If any repair is required please contact only the after-sale centres.
- The manufacturer is not responsible for any eventual damages caused by improper or faulty use.

CERAMIC HEATER


SFH 9010/SFH 9011

EN

DESCRIPTION



Front view



Rear view

- ① Turning knob LOW-OFF-HI (low power-off-high power)
- ② PTC heating element
- ③ Front safety grille for air outlet
- ④ Filter
- ⑤ Rear removable grille for air inlet

OPERATION

Turning knob to „LOW“ position you will turn on the appliance into the low power. Turning knob into „HI“ you will turn on the appliance into the high power. To turn off the appliance switch the turning knob into „OFF position“. If you are not using the appliance for long time, disconnect the power cable from power outlet.

If the appliance is tilted, you can hear a click. That is caused by safety tip-over system that is intended to turn off the appliance automatically if the appliance is being tilted.

When the appliance is turned on and it is tilted by 45°, the safety tip-over system will be activated and the appliance will be turned off. If the appliance tips over, the safety tip-over system switches the heater off automatically to protect against dangerous situation.

Double heat fuse

The device is equipped with a resetable heat fuse, which is activated and shuts off the device if it overheats. If such a situation occurs, disconnect the device from the el. power socket. As soon as the device cools down, connect it to the power socket and you may turn it on again.

To increase safety the device is equipped with a non-resetable heat fuse for the situation, where the first heat fuse malfunctions. If the non-resetable heat fuse has been activated, operation cannot be resumed. Have the device repaired at an authorised service centre.

CLEANING AND MAINTAINANCE

Before cleaning switch the turning knob into „OFF position“ at first. Unplug the power cord from power outlet and let the appliance cool down.

Cleaning appliance

To clean the appliance use soft and dry cloth. Do not splash the appliance with water or any other liquid. Do not use chemicals or abrasive detergents to clean the appliance as these may damage the surface.

CERAMIC HEATER

SFH 9010/SFH 9011

Cleaning filter

Remove the rear grille. Take out the filter from the grille. Hand wash the filter in solution of tepid water and detergent. Then rinse the filter in clean water and let it properly dry. Place clean, dried filter into the rear grille and attach it to the unit properly. Do not use the appliance without filter and rear grille.

TECHNICAL SPECIFICATIONS

220–240 V ~ 50 Hz, 1200 W

Power setting 800 W (LOW) / 1200 W (HI)

Protection class (protection against electric shock) II

Safety tip-over system 45° (±5°)

Noise level 52 dB(A)

Dimensions (w × h × d) 20 × 17 × 9,4 cm

Weight 1,4 kg

The declared noise emission level for this appliance is 52 dB(A), which represents level A of the acoustic power relative to the reference acoustic power of 1 pW.

INSTRUCTIONS AND INFORMATION REGARDING THE DISPOSAL OF USED PACKAGING MATERIALS

Dispose of packaging material at a public waste disposal site.

DISPOSAL OF USED ELECTRICAL AND ELECTRONIC APPLIANCES



The meaning of the symbol on the product, its accessory or packaging indicates that this product shall not be treated as household waste. Please, dispose of this product at your applicable collection point for the recycling of electrical & electronic equipment waste. Alternatively in some states of the European Union or other European states you may return your products to your local retailer when buying an equivalent new product. The correct disposal of this product will help save valuable natural resources and help in preventing the potential negative impact on the environment and human health, which could be caused as a result of improper liquidation of waste. Please ask your local authorities or the nearest waste collection centre for further details. The improper disposal of this type of waste may fall subject to national regulations for fines.

For business entities in the European Union

If you wish to dispose of an electrical or electronic device, request the necessary information from your seller or supplier.

Disposal in other countries outside the European Union

If you wish to dispose of this product, request the necessary information about the correct disposal method from local government departments or from your seller.



This product meets all the basic EU regulation requirements that relate to it.

Changes to the text, design and technical specifications may occur without prior notice and we reserve the right to make these changes.